

TC-K333ESL/K970ES


SERVICE MANUAL

AEP Model
TC-K970ES

E Model
TC-K333ESL



* Dolby noise reduction and HX Pro headroom extension manufactured under license from Dolby Laboratories Licensing Corporation. HX Pro originated by Bang & Olufsen.

"DOLBY", the double-D symbol  and "HX PRO" are trademarks of Dolby Laboratories Licensing Corporation.

Model Name Using Similar Mechanism	TC-K333ESG
Tape Transport Mechanism Type	TCM-200D4

SPECIFICATIONS

Recording system 4-track 2-channel stereo
Fast winding time Approx. 90 sec. (with Sony C-60 cassette)
Bias AC bias
Heads Erasing head × 1 (S&F head)
Recording head × 1 (LA head)
Playback head × 1 (LA head)
Motors Capstan motor × 1
(direct-drive linear torque BSL motor)
Reel motor × 1 (DC motor)
DC motor × 1

Signal-to-noise ratio (at peak level)

Dolby NR switch	OFF	B-Type ON	C-Type ON
Cassette			
Type IV (Sony METAL-S)	61 dB	70 dB	76 dB
Type II (Sony UX-S)	59 dB	68 dB	74 dB
Type I (Sony HF-S)	57 dB	66 dB	72 dB

Total harmonic distortion 1.0% (with Sony METAL-S cassettes)

Frequency response (DOLBY NR OFF)

Type IV cassette (Sony METAL-S)	15 - 22,000 Hz (±3 dB, IEC) 15 - 16,000 Hz [±3 dB OVU(-4dB)recording]
Type II cassette (Sony UX-S)	15 - 20,000 Hz (±3 dB, IEC)
Type I cassette (Sony HF-S)	15 - 18,000 Hz (±3 dB, IEC)

Wow and flutter ±0.04% W.Peak (IEC)
0.024% WRMS (NAB)
±0.065% W.Peak (DIN)

Inputs

Line inputs (phono jacks)	Sensitivity	77.5 mV
	Input impedance	47 k ohms
CD DIRECT INPUT	Input impedance	47 k ohms

Outputs

Line outputs (phono jacks)	Rated output level	0.44 V at a load impedance of 47 k ohms
	Load impedance	Over 10 k ohms
Phones (stereo phone jack)	Output level	0 - 2.5 mW at a load impedance of 32 ohms

General

Power requirements 120-220-240V AC, 50/60Hz (AEP, Germany)
220-230V AC, 50/60Hz (E)

Power consumption 31 W

Dimensions

Approx. 470 × 140 × 380 mm (w/h/d)
(18 1/2 × 5 1/2 × 15 inches)
including projecting parts and controls

Weight

Approx. 12.0 kg (17 lbs 7 oz)
Model for other countries: Approx. 11.2 kg

Supplied accessory

Audio connecting cord (2)
Screws (8)
Wireless remote control unit*
Sony R6 (Size-AA) batteries (2)*

*Not supplied with model for AEP countries

Design and specifications subject to change without notice.



STEREO CASSETTE DECK
SONY

TABLE OF CONTENTS

<u>Section</u>	<u>Title</u>	<u>Page</u>
SPECIFICATIONS.....		1
MODEL IDENTIFICATION		3
1. GENERAL		4
2. DISASSEMBLY		8
3. ADJUSTMENTS		
3-1. Mechanical Adjustments		10
3-2. Electrical Adjustments		12
4. DIAGRAMS		
4-1-1. IC502, 505 (CX20188) Pin Functions		17
4-1-2. IC601 (M50940-313SP) Pin Functions		18
4-1-3. IC801 (M50964-220SP) Pin Functions		19
4-1-4. IC881 (HD404240A80S) Pin Functions		20
4-2. Circuit Boards Location		20
4-3. IC Block Diagrams.....		21
4-4. Semiconductor Lead Layouts.....		22
4-5. Block Diagram		23
4-6. Printed Wiring Boards		
– Audio Section –		27
4-7. Schematic Diagram		
– Audio Section –		31
4-8. Schematic Diagram		
– Syscon Section –		35
4-9. Printed Wiring Boards		
– Syscon Section –		39
5. EXPLODED VIEWS		
5-1. Overall Section		43
5-2. Front Panel Section		44
5-3. Chassis Section		45
5-4. Mechanism Section-1		
(TCM-200D4)		46
5-5. Mechanism Section-2		
(TCM-200D4)		47
6. ELECTRICAL PARTS LIST		48

Notes on chip component replacement

- Never reuse a disconnected chip component.
- Notice that the minus side of a tantalum capacitor may be damaged by heat.


Flexible Circuit Board Repairing

- Keep the temperature of the soldering iron around 270°C during repairing.
- Do not touch the soldering iron on the same conductor of the circuit board (within 3 times).
- Be careful not to apply force on the conductor when soldering or unsoldering.



TC-K333ESL : E Model

Operating Voltage

Before connecting the unit to the power source, check that the operational voltage of your unit is the same as the local power supply.

Where purchased	Operating voltage
European countries	220 – 230 V AC, 50/60 Hz
Other countries	<p>120, 220 or 240 V AC adjustable, 50/60 Hz</p> <p>A voltage selector is located on the rear panel. If the selector must be reset, disconnect the AC power cord and set the selector to the appropriate voltage.</p> <div style="text-align: center;">  </div> <p>VOLTAGE selector</p>

SAFETY-RELATED COMPONENT WARNING!!

COMPONENTS IDENTIFIED BY MARK  OR DOTTED LINE WITH MARK  ON THE SCHEMATIC DIAGRAMS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY.

For higher quality recording/playback


- **The Dolby HX PRO* system** which improves the linearity of the tape's high-range response during recording.
- **Bias and recording level calibration** which ensures optimum recording conditions to bring out the best in every tape.
- **Three-head system (separate recording, playback and erase heads)** which allows you to instantly check the recorded sound while recording is in progress.
- **Professional-level deck design** for high mechanical stability and maximum performance.

For your convenience

- **The AMS and Memory Play functions** which provide easy access to a desired selection.
- **Timer-activated playback and recording** through the use of an optional timer.

For easier operation



- **Easy-to-read digital linear counter** which shows the elapsed recording or playing time.

MODEL IDENTIFICATION*— Specification Label —*



SECTION 1 GENERAL

This section is extracted from instruction manual.

Identification of Front Panel Parts



For details, refer to the page number indicated in ●.

- 1 POWER switch
- 2 AMS (Automatic Music Sensor) buttons ●
- 3 Remote sensor
You can remotely control this cassette deck with:
— A remote commander that came with a Sony amplifier or receiver if it has the  mark and cassette deck control capability.
— An optional Sony remote commander with the  mark and cassette deck control capability.
- 4 LINEAR COUNTER ●
- 5 Counter buttons
RESET button ●
MEMORY button ● ●
DISPLAY MODE button ●
- 6 DOLBY HX PRO button ● ●
- 7 CALIBRATION button ●
- 8 INPUT button ●
- 9 PEAK PROGRAM METER ●
- 10 REC (recording) LEVEL control ● ●
(Continued on next page.)


For details, refer to the page number indicated in ●.

(Continued from previous page.)

- 11 MONITOR switch ●
- 12 REC EQ CAL (recording equalizing calibration) switch (LOW, NORMAL, HIGH) ●
- 13 REC (recording) LEVEL control for calibration ● ●
- 14 BIAS control ● ●
- 15 DOLBY NR (noise reduction)/MPX FILTER switch ● ●
- 16 Cassette holder
- 17 OPEN/CLOSE button
- 18 Tape operation buttons and indicators
◀◀ (rewind) button
■ (stop) button
▶▶ (play) button and indicator
▶▶ (fast-forward) button
● REC (recording) button and indicator
■ PAUSE button and indicator
○ REC MUTE (record muting) button ●
- 19 PHONES jack (stereo phone jack) ●
- 20 PHONE (headphones) LEVEL control
- 21 TIMER switch ●

Remote Commander

(Except for European model)



The controls on the remote commander are identical in function and operation to those with the same name on the main unit.


For details, refer to the page number indicated in ●.

- 1 ▲ (open/close) button
- 2 DISPLAY button
- 3 Counter buttons
- 4 Tape operation buttons
- 5 CD (Compact Disc) buttons
for controlling Sony CD players
- 6 CD SYNCHRO buttons
for synchronized recording with a Sony CD player

Making an Optimum Recording According to the Tape Type


Bias and Recording Level Calibration

There are many different types of cassettes on the market, each with varying magnetic properties. Although your unit is equipped with the ATS (Automatic Tape Selection) system which sets the appropriate equalization characteristics and bias current for each tape type, an additional calibration adjustment can often produce even better results. Use the bias current and recording level calibration function to obtain the optimum recording conditions for your tape.



Bias calibration

Choosing the optimum bias current for a tape ensures minimum distortion and flat frequency response. Lowering the bias current boosts high-frequency response, but also results in higher distortion. Raising the bias, on the other hand, reduces distortion, but also dampens high-frequency response. Optimum bias is thus obtained when the bias current and high-frequency response are well balanced.




- If the bias current is higher or lower than the optimum setting for a certain tape, the frequency response changes as shown in the chart above. Changing the bias can thus be used to tailor the response to your liking, for example by slightly emphasizing the upper or lower end.
- The frequency response of metal tapes is much less affected by changes in the bias current than other tape types. With some tapes, the adjustment range of this deck ($\pm 20\%$) may therefore not be sufficient to cover every possible requirement.


Recording level calibration


Even when the recording level is adjusted correctly, using a tape with low sensitivity will result in a low playback level. The REC LEVEL calibration control allows you to compensate for sensitivity differences among tapes to equalize both recording and playback levels. This is especially important when using the Dolby NR system, since it is most effective when recording and playback levels are the same.

Making an Optimum Recording According to the Tape Type




1 Insert the cassette to be used for recording.









2 Press CALIBRATION.




3 Activate the recording test tones:


or



Playback level for an 8-kHz signal



Playback level for a 400-Hz signal




4 Adjust BIAS until both meters indicate equal playback levels.


A high reading on the upper meter indicates a low bias current.

A low reading on the upper meter indicates a high bias current.


An equal reading on both meters indicates the optimum bias current condition.



5 Adjust REC LEVEL CALIBRATION until both meters reach the recommended level (REC CAL).



The bias current is now adjusted to the optimum level and the tape sensitivity compensation has been set. Press **■**, then set CALIBRATION to OFF. Rewind the tape and start the actual recording.



Recommended level


Note

- The sound cannot be monitored during the calibration operation.
- It takes 2 to 3 seconds to stabilize the test tone level.

Making an Optimum Recording According to the Tape Type

Recording Equalization Calibration

Although bias current and equalization are automatically set by the Automatic Tape Selection (ATS) function for the tape being used, you can use the REC EQ CAL switch to change the recording characteristics according to the nature of the source material or to compensate for the particular characteristics of the tape.



Bias Calibration Recording

To modify bands of sound as required, use the REC EQ CAL switch in conjunction with bias calibration, which enables you to record according to the tape's characteristics.

• When recording music which has strong middle and low frequencies

Set the bias at flat with the REC EQ CAL switch set in the HIGH position to increase the bias current. Adjust BIAS so that the HIGH and LOW meters indicate equal readings.

• When recording music which has strong high frequencies

Set the bias at flat with the REC EQ CAL switch set in the LOW position to decrease the bias current. Adjust BIAS so that the HIGH and LOW meters indicate equal readings.

Note

With metal tape, because the amount of frequency characteristic modulation is not in proportion to that of the bias, the optimum bias current may not be obtained using the methods above.


Another use of the REC EQ CAL switch

When using a special tape, the BIAS control with the REC EQ CAL switch set in the NORMAL position may not cause the HIGH and LOW meters to indicate equal readings. If this occurs, adjust the BIAS control after setting the REC EQ CAL switch to HIGH or LOW.


Recording

What is the Dolby HX PRO System?

The Dolby HX PRO system provides improved linearity in high-range frequency response during recording. Tapes recorded with this system retain the same high quality even when played back on other tape decks.



As shown above, characteristics such as output level and distortion differ widely according to the bias (high-frequency) current. In conventional systems, the bias current is susceptible to variations in certain recording signals (see diagram below) which may cause fluctuations in frequency response, distortion, or other unwanted characteristics.




With the Dolby HX PRO system, the effective bias amount added to the bias current is controlled in millisecond units to greatly reduce distortion, improving linearity in high-range response and ensuring high-intensity recording with minimal distortion and noise.

SECTION 2


DISASSEMBLY

- If the parts are marked with the numbers ①, etc., remove them in the order of the number.

Cassette Holder




Ornamental Plate



Pinch Lever/Lever FR

- ① - ④ : Pinch lever S
- ① and ② : Pinch lever T
- △ and △ : Lever FR




Comparator Board/Capstan Board/Flywheel/FG Board

△ and ▽ : Comparator board


① - ④ : Capstan board

① - ③ : FG board (after removing 1 and 2)


Note: To remove the above parts with the base (D1) assembly, remove the four screws marked with ★.



MD board



Reel Motor Board




SECTION 3 ADJUSTMENTS

3-1. MECHANICAL ADJUSTMENTS

PRECAUTION

1. Clean the following parts with a denatured-alcohol-moistened swab:

record/playback head	pinch roller
erase head	rubber belts
capstan	idlers
2. Demagnetize the record/playback and erase head with a head demagnetizer.
3. Do not use a magnetized screwdriver for the adjustments.
4. After the adjustments, apply suitable locking compound to the parts adjusted.
5. The adjustments should be performed with the rated power supply voltage unless otherwise noted.



Tape Path Adjustment


- Refer to Adjustment Position on page 12.

Note: When using the adjustment methods for other than replacement reasons, please do not tamper unnecessarily with the adjustment screws or the erasehead because either the supply pinch roller guide or the record/playback head will be made the standard tape paths. Moreover, when it is necessary to adjust and replace two or more of any of the heads and/or pinch rollers, replace them one by one, completely taking out the first tape path, and then replacing the second one.

Preparation:


1. Mirror cassette CQ009C 8-909-708-01
(or CQ012C 8-909-708-02)

If one does not have this, cut out the sections of a 120-minute cassette shell as indicated below and use that cassette.



2. Phillips screwdriver (medium-size):
For the head adjustment screws
Blade-type screwdriver (large-size):
For the supply pinch roller adjustment screws
3. Pen light
4. WS-48B (3 kHz, 0 dB)
5. P-4-A100 (10 kHz, -10 dB)

Definition of Terms: The figures are of a record/playback head.



Adjustment Method:

Supply Pinch Roller

Note: Only perform this adjustment when the supply pinch roller is to be replaced.


1. Insert the mirror cassette and put the unit in record/playback mode.
2. Check to see whether the tape is curling at the record/playback head guide or the pinch roller guide.
If it is curling, remove the curl by adjusting the tape curl adjustment screw. Then, check that the tape is running past the middle of the erasehead.

Record/playback Head

Note: Only perform this adjustment when the record/playback head is to be replaced.

1. Insert the mirror cassette and put the unit in record/playback mode.
2. **(Height Adjustment)** Check to see if the tape is curling at the tape guide of the head. If it is curling, tighten screws ②, ③, and ④, respectively by the same angle, moving the head so that it


remains at the same angle throughout the procedure. If it curls on the bottom side of the mirror cassette (actually the inner side), tighten all the screws equally; but loosen them if the tape begins to curl on the top side (outer side).



3. (Declination Adjustment) While in the record/playback position, set the back tension to 0 (wind the supply reel with something thin like a pencil in a counterclockwise direction) and make sure there is no curling or shifting (shifting up/shifting down) at the guide of the record/playback head.

Because shifting can only occur due to a difference in the width of the tape and that of the tape guides (curling will otherwise occur), it is necessary to pay close attention since it can be easily overlooked. When there is a shift, tighten screws **E** and **F** equally and change the declination of the head. If the tape is shifting up, tighten the screws, and if it is shifting down, loosen them.


4. Repeat the adjustments in steps 2 and 3 and fine adjust the height and the declination.
5. (Preliminary Azimuth Adjustment) After demagnetizing and cleaning the adjustment head, play back WS-48B (3 kHz, 0 dB). Turn screw **G** so that the reading on the level meter of the unit or that of the level meter connected to LINE OUT is maximized. If the screw is turned at least half a revolution, repeat the adjustments from step 1.
6. (Tape Path Check) Connect the oscilloscope to LINE OUT and play back P-4-A100 (10 kHz, -10 dB) to display a resurge waveform. After 20 seconds of record/playback (after the tension within the loop has been increased sufficiently), make sure the variation in the resurge is within ± 90 degrees (within ± 45 degrees is desired). If the variation is greater than this, it is because the declination and/or the height adjustment is not perfect. Repeat the adjustments from step 1.



Erasehead


Note: Only perform this adjustment when the erasehead is to be replaced.

1. Insert the mirror cassette and put the unit in record/playback mode.
2. (Azimuth Adjustment) Adjust the azimuth of the erasehead by adjusting screws **E** and **F** so that the tape runs as evenly as possible.




(The erasehead as seen when erasing the mirror cassette.)

3. (Height adjustment) Turn screws **D**, **E**, and **F** all by the same angle so that the portions of the erasehead visible at top and bottom are nearly of equal width. If the width at the top is greater, tighten the screws; if the width at the bottom is greater, loosen the screws.





4. (Declination Adjustment) Leaving it in the playback position, put the back tension to 0 and make certain the erasehead part and supply pinch roller guide part do not shift. If there is a shift, turn the screw ⑩ and change the declination. Looking at it using the mirror cassette, if the tape shifts up, tighten the screw, and if it shifts down, loosen the screw.
5. Repeat the adjustments beginning with step 2 and fine adjust the height and declination. And make sure the tape does not curl up on the pinch roller guide or the guide part of the record/playback head.
6. (Depth Adjustment) In order to make the entire head play the tape smoothly, and to make sure the depth of the erasehead is neither too shallow nor too deep, loosen screw ⑥ a bit.

**Check**

1. Check to make sure that there are no curls or shifts throughout the whole tape path and that the tape runs smoothly.
2. Reapply the locking compound to the adjusted screws. (The locking compound should only be applied to screw ⑥ after the azimuth has been adjusted.)

Adjustment Position : As seen from the cassette, side (top) and MD as seen head on (bottom).

**Pinch Roller Pressing Force Measurement**


Mode : playback

Hook needle of the tension gauge to the pinch roller shaft and push back pinch roller to detach it from capstan. Then, return it gradually to capstan and read the gauge when the pinch roller begins turning.

Standard Limits :

Tape-up side : 270 – 350g (9.5 – 12oz)

Supply side : 180 – 280g (6.4 – 9.9oz)

**3-2. ELECTRICAL ADJUSTMENTS**

Note: The adjustment should be performed in the order given in this service manual.

The adjustments should be performed for both L-CH and R-CH.

- Simultaneous REC/PB Mode:

Input the signals to LINE IN terminal and set to REC mode. Set the monitor switch to TAPE, and monitor the recorded signal from LINE OUT terminal.

- Switch Position:

DOLBY NR..... OFF
 TIMER..... OFF
 MONITOR..... TAPE
 HX PRO OFF
 CALIBRATION..... OFF
 CD DIRECT..... OFF
 BIAS CENTER CLICK
 REC LEVEL CENTER CLICK

- Standard Record:


Deliver the standard input signal level to the input jack and set the REC LEVEL control to obtain the standard output signal level.

Standard Input Level

Input Terminal	LINE IN
source impedance	10 k Ω
input level	0.25 V (–10 dB)

Standard Output Level

Output Terminal	LINE OUT
load impedance	47 k Ω
output level	0.44 V (-5 dB)




Torque Adjustment and Measurement

1. Insert a tape for torque measurement, CQ-102C, and put the set to PLAY mode. Adjust RV801 so that the reading of the torque meter is 40 ± 5 g.cm.
2. After the adjustment, measure the back-tension and the FF/REW torque and check that the following specifications are satisfied.

Torque	Torque Meter	Reading
FWD	CQ-102C	35 - 45 g·cm (0.49 - 0.64 oz·inch)
FWD Back tension	CQ-102C	7 - 12 g·cm (oz·inch)
FF/REW	CQ-201B	55 - 120 g·cm (0.97 - 1.67 oz·inch)

Tape Speed/WOW Check

Procedure:



1. Measure the output frequency and the WOW value while playing back the tape top of the test tape.
2. Turn over the test tape, measure the output frequency and the WOW value, and check the difference from the values of the step 1.

Adjustment Limits :


TAPE SPEED deviation:	within 2,990 to 3,010 Hz
TAPE SPEED fluctuating width:	within 2,990 to 3,010 Hz
WOW (WRMS):	0.037 % or less

MPX FILTER Check

Setting : DOLBY switch : OFF
MPX FILTER switch : OFF

Procedure :

1. Mode: stop



2. Apply 315Hz, 0.25V (-10dB) signal and adjust REC LEVEL (RV501) control so that the LINE OUT level is 0.44V (-5dB).
3. Apply 19kHz 0.25V (-10dB) signal and confirm that the LINE OUT level is 0.013V (-35dB) or less.


Adjustment Limits :

DOLBY NR switch : B or C
MPX FILTER switch : Line output level when ON.
315Hz : Within 0.49 to 0.39V (within -4dB to -6dB)
19kHz : 0.013V (-35dB) or less


Record/Playback Head Azimuth Adjustment

Procedure :


1. Mode : playback



2. Turn the adjustment screw for the maximum output levels. If these levels do not match, turn the adjustment screw until both of output levels match together within 0.5dB.



Adjustment Location :




Playback Level Adjustment

Procedure:

Mode: playback

test tape
P-4-L300
(315 Hz, 0 dB)



Adjust RV101 (L-CH) and RV201 (R-CH) to obtain the specified LINE OUT level.

Adjustment Limits :

LINE OUT level: 0.42 to 0.46 V
(-5.3 to -4.7 dB)


Level difference between channels:
less than 0.5 dB

Check that the LINE OUT level does not change in playback mode while changing the mode from playback to stop several times.


3. Phase check

- Play mode -

Reference tape for adjustment
P-4-A100
(10kHz, -10dB)




- Check that the phase difference between L-ch and R-ch is within 0 ~ (same to 90°).



Bias OSC Frequency Adjustment

Procedure :

- Record mode



- Connect the frequency counter to the inductor which functions at 10 mH. (When the inductor is a closed magnetic circuit, redesign the inductor to be an open magnetic circuit.)
- Remove the cassette lid, insert the cassette, and put the unit into REC mode.
- Move the inductor from the side in close to the erase head to check the value of the bias.
- Adjust CP501 so that the reading on the frequency counter is 105kHz ± 1kHz.

Bias current adjustment

- Set the HX PRO switch to ON and insert the METAL tape.
- Set RV104, RV204, RV105, RV205, RV106, and RV206 to be in the center position.
- Connect a digital voltmeter to CNE504 (between 2-1 and 2-3) and adjust the adjustment cores of T101 and T201 so that the voltage is minimized.

CrO₂ Bias and Record Level Adjustment

Note : This adjustment should be made before Record Bias Adjustment.


Setting:

REC LEVEL knob: standard record position
(See page 12.)

HX PRO switch : ON

Procedure:

- Mode: simultaneous REC/PB



2. Adjust RV106 (L-CH) and RV206 (R-CH) so that the playback output level of 10kHz signal is 0.3dB - 0.3dB with respect to that of 315Hz. . . . Record Bias Adjustment.
3. Adjust RV102 (L-CH) and RV202 (R-CH) so that the playback output level of 315Hz is -25.3dB to -24.7dB. . . . Record Level Adjustment.


Metal Bias Adjustment

Setting :

REC LEVEL Knob : standard record position
(See page 12.)

Procedure :

1. Mode : simultaneous REC/PB



2. Adjust RV510 (L-CH) and RV205 (R-CH) so that the difference between the playback output at 315Hz and that of 10kHz in R-CH is within 0.5 dB to -0.5dB.


Normal Bias Adjustment

Setting:

REC LEVEL knob: standard record position
(See page 12.)

Procedure:

1. Mode: simultaneous REC/PB



2. Set the HXPRO switch to ON.
3. Adjust RV103 (L-CH) and RV203 (R-CH) so that the difference between the playback output at 315Hz and that of 10kHz in R-CH is within 0.5dB to -0.5dB.
4. Set the HXPRO switch to OFF.
5. Adjust RV104 (L-CH) and RV204 (R-CH) so that the difference between the playback output at 10kHz when the HXPRO is ON and that of 10kHz when ON is within 0.5dB to -0.5dB.

Meter Level Adjustment


Setting :

REC LEVEL Knob : standard record position
(See page 12.)

MONITOR : SOURCE

Procedure :

1. Stop mode




2. Adjust RV107 (L-CH) and RV207 (R-CH) so that a reading of the meter is set to 0VU and the lamp is lit.
3. Adjust REC level so that the LINE OUT level is set to +10dB and check that all the lamps are lit.

Calibration OSC and Calibration Meter Adjustment

Setting : CALBRATION switch : ON

Procedure (OSC OUT LEVEL) :

1. Mode : record (no-signal (LINE INPUT))




2. Adjust RV504 so that a check-point level at 400Hz is +10dB.
3. Adjust RV503 so that a check-point level at 8kHz is +10dB.


Procedure (CAL METER ADJ) :

1. Put the set in record mode and adjust RV208 (HIGH) so that HIGH FREQ segments in the CAL LEVEL meter light thoroughly up to 0 VU as shown in the figure below. Segment (a) may flicker.

2. Preset RV108 (LOW) so that segment (a) in LOW FREQ CAL LEVEL meter lights. Then adjust RV204 to the point where segment (a) goes out.



Location Diagram of the Adjustment Parts



SECTION 4

DIAGRAMS

4-1-1. IC502, 505 (CX20188) PIN FUNCTIONS

An electronic switch circuit for the operation mode control is included. Controls are performed by adding direct current voltages VH, VM, and VL to Dolby OFF/B/C and calibration/REC/Playback terminals.

CX20188	Pin name	Description
Pin No.		
1.	Vcc	Positive power supply terminal.
2, 41.	REC IN	Recording input terminal.
3.	I REF	Reference current input terminal.
4, 39.	PB IN	Playback input terminal.
5.	CAL/REC/PB	Calibration/recording/playback select terminal
6, 37.	PB FB	Playback feedback terminal.
7, 36.	REC FB	Recording feedback terminal.
8, 35.	GND	GND terminal.
9, 34.	LINE OUT	Line output (decode output) terminal.
10, 33.	SSK	Spectral skewing switch terminal.
11, 32.	VF IN	Encode circuit input terminal.
12, 31.	HPF H	HLS high-pass filter terminal.
13, 30.	TCH 2	HLS detector time constant terminal 2.
14, 29.	TCH 1	HLS detector time constant terminal 1.
15, 28.	WT H	HLS encoder error reduction terminal.
16, 27.	TCL 2	LLS detector time constant terminal 2.
17, 26.	TCL 1	LLS detector time constant terminal 1.
18, 25.	WT L	LLS encoder error reduction terminal.
19, 24.	HPF L	LLS high-pass filter terminal.
20, 23.	ANT S	Anti-saturation terminal.
21, 22.	REC OUT	Recording output (encode output) terminal.
38.	OFF/B/C	Dolby NR off/B type/C type select terminal.
40.	CAL IN	Calibration input terminal.
42.	Vee	Negative power supply terminal.

MODE	VOLT
VH	3 to 9.9V
VH	-0.7 to 0.7V
VL	-9.9 to -3

4-1-2. IC601 (M50940-313SP) PIN FUNCTIONS

Level meter display of 24-segment fluorescent display, etc., are performed by receiving direction from the master microcomputer (IC801).

Pin No.	Pin name	I/O	Description
1.	Vref	I	A/D input-port reference voltage input(+5V)
2.	ϕ L	I	Not used. (Connected to +5V)
3.	ϕ R	I	Not used. (Connected to +5V)
4.	DATA	I	Data input from the master microcomputer(IC801)(analog)
5.~6.	ADE1~ADRO	I	Data input from the master microcomputer(IC801)(analog)
7.	KEY	I	Not used. (Connected to +5V)
8.	LEVEL L	I	Level meter L-CH input(analog) from the meter amplifier(IC514)
9.	LEVEL R	I	Level meter R-CH input(analog) from the meter amplifier(IC514)
10.~13.	$\overline{\text{GRID6}}\sim\overline{\text{GRID3}}$	0	Not used.
14.~15.	$\overline{\text{GRID2}}\sim\overline{\text{GRID1}}$	0	Fluorescent display grid output
16.	$\overline{\text{COO}}$	0	Not used.
17.	$\overline{\text{PLAY}}$	0	Not used. (Connected to pin ⑩.)
18.	$\overline{\text{PLAY}}$	0	Not used.
19.	$\overline{\text{PAUSE}}$	0	Not used.
20.	$\overline{\text{REC}}$	0	Not used.
21.	$\overline{\text{TAPE}}$	0	Fluorescent display segment output("TAPE" displayed). "L": TAPE displayed. "H": SOURCE displayed.
22.	$\overline{\text{OVER LEVEL}}$	0	Fluorescent display segment output("OVER LEVEL" displayed). It is displayed when "L".
23.	$\overline{\text{TYPE I}}$	0	Fluorescent display segment output("TYPE I" displayed). It is displayed when "L".
24.	$\overline{\text{TYPE II}}$	0	Fluorescent display segment output("TYPE II" displayed). It is displayed when "L".
25.	$\overline{\text{TYPE IV}}$	0	Fluorescent display segment output("TYPE III" displayed). It is displayed when "L".
26.	CNVss	-	Power supply terminal(GND)
27.	$\overline{\text{RESET}}$	I	Reset input
28.	XIN	I	Clock input(4MHz)
29.	XOUT	0	Clock output.
30.	XCIN	-	Not used. (Connected to GND)
31.	XCOUT	-	Not used.
32.	Vss	-	Power supply terminal(GND)
33.	Φ	0	Not used.
34.	VER	I	Version switching input(Always set to "L")
35.	$\overline{\text{TEST}}$	I	Test mode input. "L": All the lamps of the meter are lit.
36.	CAL	I	Calibration switch(S602) input. "L": CAL mode. "H": Normal mode.
37.	IN	I	Not used. (Connected to GND.)
38.	VP	I	Fluorescent display segment output's pull-down power supply terminal(-22V)
39.~62.	S23~S0	0	Fluorescent display segment output(meter display)
63.	AVcc	-	Power supply terminal(+5V)
64.	Vcc	-	Power supply terminal(+5V)


4-1-3. IC801 (M50964-220SP) PIN FUNCTIONS

Pin No.	Pin name	I/O	Description
1.	VCC		Power supply: +5V.
2.	AVss		Analog GND.
3.	Vref	I	A/D port reference voltage input.
4.	DA		Not used for this model.
5.	PWM		Not used for this model.
6.	P.OFF		Not used for this model. Connected to GND.
7.	LED	O	PAUSE LED output.
8.	LED	O	REC LED output.
9.	LED	O	PLAY LED output.
10.	AD1	I	Key input. 0V=▲, 1V=■, 2V=◀, 3V=▶, 4V=●.
11.	AD2	I	Key input. 0V=▶, 1V=■, 2V=◀, 3V=▶, 4V=○.
12.	AMS SIG	I	AMS signal input. No song detected = Low. Song detected = High.
13.	AD4	I	Key input. 2V = DISPLAY, 3V = MONITOR.
14.	CODE	I	Remote control category select switch.
15.	ALB		Connected to 5V.
16.	φR	I	Take-up reel base sensor input.
17.	φL	I	Supply reel base sensor input.
18.	C RESET		Model select input. Connected to GND.
19.	C MEMORY		Model select input. Connected to GND.
20.	COO		Not used for this model.
21.	POWER IN	I	Power on and off detection.
22.	SIRW	I	SIRCS phase input.
23.	SIRE	I	SIRCS reverse phase input.
24.	T-REC	I	Timer REC switch input.
25.	T-PLAY	I	Timer PLAY switch input.
26.	INT	I	External interruption input. Interruption process is performed when the power is on or off.
27.	Vss		GND.
28.	RESET	I	Reset input.
29.	XIN	I	Clock input (4 MHz).
30.	XOUT	O	Clock output (4 MHz).
31.	φout		Not used for this model.
32.	Vss		GND.
33.	C1	I	Rotary encoder input to detect the position of the head base of the mechanical block.
34.	C2	I	Rotary encoder input to detect the position of the head base of the mechanical block.
35.	C3	I	Rotary encoder input to detect the position of the head base of the mechanical block.
36.	C4	I	Rotary encoder input to detect the position of the head base of the mechanical block.
37.	OPEN SW	I	OPEN switch input of the mechanical block.
38.	CLOSE SW	I	CLOSE switch input of the mechanical block.
39.	DOOR SW	I	DOOR switch input of the mechanical block.
40.	REC SW	I	REC switch input of the mechanical block.
41.	M PLAY	O	Reel motor rotates at PLAY speed.
42.	M FAST	O	Reel motor rotates at FF/REW speed.
43.	M FWD	O	Reel motor rotates.
44.	M REV	O	Reel motor rotates in reverse.
45.	CAM DOWN	O	Head base DOWN output of the mechanical block
46.	CAM UP	O	Head base UP output of the mechanical block
47.	C OFF	O	Counter light-off output
48.	M OFF	O	Meter light-off output
49.	BIAS	O	Bias oscillation on and off control
50.	R Mt	O	REC MUTE.
51.	M Mt		Not used for this model.
52.	T Mt	O	Tape MUTE. Goes to low when the tape is being played.
53.	S Mt	O	Source MUTE. Goes to low three seconds after the power is on.
54.	AMS	O	AMS switch output. Goes to low when AMS is being used.
55.	MONITOR		Not used for this model. Connected to GND.
56.	HALF		Not used for this model. Connected to GND.
57.	DAT3	O	Outputs parallel data for the counter display.
58.	DAT2	O	Outputs parallel data for the counter display.
59.	DAT1	O	Outputs parallel data for the counter display.
60.	DATO	O	Outputs parallel data for the counter display.
61.	DATD	O	Outputs parallel data for the counter display.
62.	CLK	O	Clock output to transmit the parallel data.
63.	LATCH	O	Output for latching the transmitted data.
64.	CAL IN	I	CAL switch input.

4-1-4. IC881 (HD404240A80S) PIN FUNCTIONS


Fluorescent dynamic display is performed by receiving count data from the master microcomputer (IC801)

Pin No.	Pin name	I/O	Description
1.	SG3	O	Fluorescent display grid output
2.	G4	O	Fluorescent display grid output
3.	dot	O	Fluorescent display segment output
4.	P DWN	I	Pull-down power supply terminal for fluorescent display segment output (-22V)
5.~11.	g~a	O	Fluorescent display segment output
12.	-	-	Not used.
13.~16.	DIM1~DIM4	I	Dimmer input (Pins ⑭ and ⑯ are "H". Others are opened and fixed: Blanking time 550usec; grid ON time 450usec.)
17.~20.	-	-	Not used.
21.	Vcc	-	Power supply terminal (+5V)
22.	SCK	I	Shift clock input (250kHz) from the master microcomputer (IC801)
23.	SI	I	Serial data input (Data are sent by 1 byte every 6msec.) from the master microcomputer (IC801)
24.~25.	-	-	Not used.
26.	RESET	I	Reset input from the master microcomputer (IC801). Reset when "H".
27.	TEST	I	Connected to +5V.
28.	OSC1	I	Clock input (4MHz)
29.	OSC2	I	Clock input (4MHz)
30.	GND	-	Power supply terminal (GND)
31.~34.	-	-	Not used.
35.	MLED	O	Not used. (Connected to +5V)
36.~40.	-	-	Not used.
41.	G2	O	Fluorescent display grid output
42.	G1	O	Fluorescent display grid output


4-2. CIRCUIT BOARDS LOCATION

4-3. IC BLOCK DIAGRAMS



IC502, 505 CX20188



IC902 CX20174




IC952 TC-9142P

IC508 μ PC1297CA


IC802 BA6219B

IC803 LB1641




4-4. SEMICONDUCTOR LEAD LAYOUTS


BA6219B



M5F7807
RC79L12A



M5F7907
RC78L12A




2SK246-GR2



2SK147



2SB716
2SC945-P
2SC1815-GR
2SD666A



DTA114ES
DTA144ES
DTC114ES
DTC124ES
DTC143ES
DTC144ES
2SB1370-EF
2SC2603-EF
2SC2682-QPE
2SC3623A-LK
2SD2061-EF




2SA985A
2SC2275A




2SB734-34




2SA1175-HFE
2SD1020-HFE




RD5.1JS-B1
HZS6C1L
HZS6C3L
UZL-6M2
UZL-24L
1SS202-1




HZ6B2L
HZ12B2L
10E2N



30DF2




SEL4414E-C
SEL4814A-CD



SEL4214S




4-5. BLOCK DIAGRAM






• Semiconductor Location








Ref. No.	Location	Ref. No.	Location
D101	I-16	Q105	B-10
D102	I-16	Q106	A-12
D103	I-16	Q107	I-8
D201	H-15	Q108	H-9
D202	H-15	Q109	H-9
D203	H-16	Q110	H-9
D501	E-15	Q111	H-9
D502	A-15	Q112	H-14
D503	A-15	Q113	H-13
D509	C-9	Q114	H-14
D510	C-9	Q116	G-13
D511	H-8	Q117	G-14
D512	I-15	Q118	I-11
D514	H-8	Q201	D-11
D515	H-8	Q202	D-11
D516	J-16	Q203	D-10
D517	K-15	Q204	D-10
D519	A-14	Q205	D-10
D520	A-14	Q206	E-12
D521	A-14	Q207	J-8
D522	G-6	Q208	J-9
D523	G-8	Q209	J-9
D524	I-3	Q210	J-9
D525	H-11	Q211	J-9
D526	H-13	Q212	H-14
D527	G-10	Q213	H-13
D601	D-22	Q214	H-14
D602	D-22	Q216	G-13
D603	B-19	Q217	G-14
D604	B-19	Q218	J-11
D605	C-19	Q501	A-13
D606	B-22	Q502	A-13
D607	E-23	Q503	A-13
D608	E-23	Q504	D-13
D609	E-22	Q505	E-15
D610	D-22	Q506	E-15
D611	D-22	Q507	E-15
D612	D-22	Q508	A-15
D613	D-23	Q509	A-10
D614	C-22	Q510	B-9
D615	D-22	Q511	B-9
D616	D-23	Q512	A-9
D617	C-22	Q513	E-10
D618	C-22	Q514	D-9
D619	C-22	Q515	D-9
D620	D-20	Q516	E-9
IC101	B-13	Q518	J-15
IC102	B-13	Q519	J-15
IC201	E-13	Q520	I-15
IC202	E-13	Q522	I-13
IC501	C-11	Q523	I-14
IC502	C-15	Q524	I-14
IC503	E-14	Q529	J-14
IC504	I-5	Q534	K-14
IC505	I-7	Q533	J-16
IC506	I-10	Q534	J-15
IC507	B-5	Q535	G-14
IC508	J-11	Q536	J-15
IC509	J-16	Q537	B-9
IC510	J-15	Q538	D-9
IC511	G-7	Q539	H-11
IC512	G-13	Q540	G-11
IC513	G-15	Q601	B-22
IC514	H-15	Q602	B-23
IC515	K-14	Q603	B-18
IC518	H-5	Q604	B-18
IC519	H-5	Q605	B-18
IC601	B-21	Q606	B-18
IC602	C-22	Q607	B-19
Q101	B-11	Q608	B-19
Q102	B-11	Q610	B-19
Q103	B-10	Q611	B-22
Q104	B-10		



Note on Mounting Diagram:
• ○ : parts extracted from the component side.
• ● : parts mounted on the conductor side.







Note: The components identified by mark  or dotted line with mark  are critical for safety. Replace only with part number specified.

- o  : B+ Line
- o  : B- Line
- o  : adjustment for repair.
- o Voltage and waveforms are dc with respect to ground under no-signal (detuned) conditions.
 - no mark: STOP
 -  : PLAY
 : REC
 : FF
 : REW

II : PAUSE
 I : NORMAL TAPE
 II : CrO₂ TAPE
 IV: METAL TAPE
- o Voltages are taken with a VOM (input impedance 10M Ω)
- o Voltage variations may be noted due to normal production tolerances.
- o Signal path,
 -  : PB (DECK A)
 -  : REC (DECK A)



4-9. PRINTED WIRING BOARDS - SYSCON SECTION -



• Semiconductor Location

Ref. No.	Location
D701	D-11
D702	D-11
D703	D-12
D704	D-11
D705	C-15
D706	C-15
D707	C-14
D708	C-14
D709	C-14
D710	C-14
D711	C-15
D712	D-15
D751	G-20
D752	D-20
D753	D-22
D754	D-23
D755	C-24
D756	C-24
D757	C-24
D758	D-24
D801	F-22
D802	F-22
D881	J-14
D882	J-15
D883	I-16
IC801	F-23
IC802	H-21
IC803	G-21
IC881	G-14
IC882	G-16
IC902	I-6
IC951	J-3
IC952	I-2
IC1001	G-10
IC1002	G-9
Q701	B-15
Q751	C-21
Q752	C-22
Q753	C-23
Q754	D-24
Q755	C-24
Q756	C-21
Q757	D-22
Q758	D-22
Q759	D-23
Q801	G-21
Q802	H-21
Q803	H-23
Q804	H-24
Q805	G-24
Q806	E-24
Q807	E-24
Q808	F-24
Q809	E-22
Q810	E-22
Q811	F-22
Q812	F-22
Q813	F-22
Q814	F-22
Q815	F-21
Q816	F-21

Note on Mounting Diagram:
• ○ : parts extracted from the component side.

SECTION 5

EXPLODED VIEWS

NOTE:

- -XX, -X mean standardized parts, so they may have some differences from the original one.

- Color Indication of Appearance Parts
Example:


KNOB, BALANCE (WHITE)...(RED)

Parts color Cabinet's color

- Items marked "*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- The mechanical parts with no reference number in the exploded views are not supplied.
- Hardware (# mark) list is given in the last of this parts list.

The components identified by mark Δ or dotted line with mark Δ are critical for safety.
Replace only with part number specified.

5-1. OVERALL SECTION




Ref. No.	Part No.	Description
1	3-356-942-01	SCREW (2.6X6), TAPPING
2	3-364-438-21	WINDOW, CASSETTE
3	3-356-923-01	LID, CASSETTE
4	X-3362-818-1	KNOB (DIA. 12) ASSY (B), SQUARE
5	3-364-475-31	PANEL, FRONT
6	3-703-685-21	SCREW (+BV 3X8)
7	4-908-848-01	EMBLEM, SONY
8	4-908-044-11	ESCUTCHEON, POWER KNOB
9	3-364-444-01	ESCUTCHEON (L)
10	3-364-442-11	WINDOW, COUNTER
11	3-831-441-XX	PAPER, INTERCEPTION

Remark


Ref. No.	Part No.	Description	Remark
12	3-364-443-01	WINDOW, METER	
13	3-364-447-01	ESCUTCHEON (R)	
14	9-911-842-XX	CUSHION (S)	
15	X-3304-959-1	PANEL (LEFT) ASSY, SIDE	
16	4-923-474-01	RING, ORNAMENTAL	
17	3-704-366-01	SCREW (CASE) (M3X8)	
18	* 3-350-489-11	CASE	
19	X-3304-960-1	PANEL (RIGHT) ASSY, SIDE	
20	4-885-979-11	SCREW (4X25)	
21	X-3304-944-1	FOOT ASSY	



5-2. FRONT PANEL SECTION



Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
51	* 3-364-474-01	PANEL (BASE)		62	3-831-441-XX	SPACER	
52	4-922-518-11	KNOB (TIMER)		63	3-831-441-11	SPACER	
53	4-908-046-01	KNOB, SQUARE		64	X-3362-327-1	BUTTON ASSY	
54	4-864-307-00	RING		65	2-132-434-01	CLIP, WIRE	
55	3-703-150-11	STOPPER, WIRING		66	* A-2006-355-A	METER BOARD	
56	* 1-637-517-11	AC SW BOADR		67	* 1-637-519-11	REC VOL BOARD	
57	* 1-637-518-11	TIMER SW BOARD		68	* 1-637-523-11	MONITOR SW BOARD	
58	* 1-637-521-11	H. P. AMP BOARD		69	* 1-637-520-11	REC EQ SW BOARD	
59	3-655-653-21	BAND (TAITON), BINDING		70	3-364-441-01	BUTTON	
60	4-928-635-01	SCREW, +BV (2.6X8) TAPPING		71	3-364-440-01	KNOB (L)	
61	* 1-637-516-11	COUNTER BOARD		72	3-364-439-01	KNOB (R)	


5-3. CHASSIS SECTION



Note: The components identified by mark  or dotted line with mark  are critical for safety. Replace only with part number specified.

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
101	3-703-685-21	SCREW (+BV 3X8)		114	* 1-637-512-11	RECT. BOADR	
102	3-703-150-11	STOPPER, WIRING		115	* 3-329-937-02	CLIP, WIRE	
103	3-701-947-15	LABEL (T2.5A), FUSE		116	* 3-350-482-21	PANEL, BACK (K970ES)	
104	* 1-533-213-31	HOLDER, FUSE			* 3-350-482-31	PANEL, BACK (K333ESL:E)	
105	* 3-356-925-01	HEAT SINK		117	* 1-637-522-11	PIN JACK BOARD	
106	* A-2006-354-A	SYS CON BOARD		118	A-2006-353-A	REC BOARD	
107	* 4-363-146-21	HEAT SINK, V. OUT		119	△1-569-007-11	ADAPTER, CONVERSION 2P (K333ESL:E)	
108	* 3-346-266-12	PLATE, GROUND		120	A-2006-513-3	V. S BOARD (K333ESL:E)	
109	4-820-330-31	SCREW (K970ES)		F701	△1-532-286-00	FUSE, TIME-LAG (2.5A)	
	4-886-821-11	+PTTWH 3X6(S) (K333ESL:E)		F702	△1-532-286-00	FUSE, TIME-LAG (2.5A)	
110	3-346-266-21	PLATE, GROUND		S702	△1-157-009-11	SELECTOR, VOLTAGE (K333ESL:E)	
111	A-2006-364-A	PB BOARD		T701	△1-450-451-11	TRANSFORMER, POWER (K970ES)	
112	△1-574-383-11	CORD, POWER (K970ES)			△1-450-453-11	TRANSFORMER, POWER (K333ESL:E)	
	△1-559-297-32	CORD, POWER (K333ESL:E)					
113	* 3-703-244-00	BUSHING (2104), CORD (K970ES)					
	* 4-916-783-01	BUSHING, CORD (K333ESL:E)					


5-4. MECHANISM SECTION-1
TCM-200D4



Ref. No.	Part No.	Description	Remark
151	X-3362-671-1	HOLDER (BG) ASSY, CASSETTE	
152	3-558-708-21	WASHER, STOPPER	
153	* 3-356-717-01	LEVER (JOINT)	
154	3-356-626-01	SPRING, TENSION	
157	3-356-932-01	LEVER (LA)	
158	3-356-927-01	SPRING (LEFT), TORSION	
159	3-356-933-01	LEVER (LB)	
160	3-356-928-01	PLATE (A), ORNAMENTAL	
161	* 3-356-929-01	ABSORBENT, VIBRATION	
162	3-356-931-01	LEVER (RB)	
163	3-356-926-01	SPRING (RIGHT), TORSION	
164	3-356-930-01	LEVER (RA)	
165	X-3356-613-1	PLATE ASSY, ORNAMENTAL (IN CLUDED. SLF-325C	
168	3-564-138-00	GUIDE (S), TAPE	
169	3-356-652-01	NUT (PINCH LEVER S)	
170	X-3356-621-1	LEVER (PINCH LEVER S) ASSY	
171	3-356-660-01	LEVER (PS)	
172	3-356-661-01	SPRING (PINCH LEVER S), TORSION	
173	3-356-657-01	SPRING (PS), COMPRESSION	
174	3-669-465-00	WASHER (1.5), STOPPER	
175	X-3356-641-1	LEVER (FR2) ASSY	
176	3-356-614-01	SLIDER (BRAKE)	
177	* X-3356-608-1	LEVER (LIFTER) ASSY	
178	3-356-601-11	SCREW, STEP	

Ref. No.	Part No.	Description	Remark
179	X-3356-623-1	LEVER (BT) ASSY	
180	3-362-308-01	CAP (REEL)	
181	3-319-224-31	DAMPER, SMALL	
182	X-3356-629-1	GEAR (S) ASSY	
183	X-3356-627-1	GEAR (T) ASSY	
184	3-356-710-01	SHAFT (LEFT) (CASSETTE HOLDER)	
185	3-356-658-01	SPRING (LIMITER H), TENSION	
187	* X-3362-199-1	SLIDER (HEAD CHASSIS D) ASSY	
188	3-332-763-01	RING, OIL RESERVOIR	
190	3-356-656-01	SPRING (HEAD PC BOARD), LEAF	
192	X-3356-620-1	LEVER (PINCH LEVER T) ASSY	
194	3-318-433-01	SPRING	
195	* 3-576-977-00	BRACKET, E. HEAD	
196	* 1-608-268-00	PC BOARD, ERASE HEAD	
197	X-3356-611-1	HOLDER (A) ASSY, CASSETTE	
198	3-356-624-01	SPRING, TENSION	
199	3-356-619-01	SPRING (B), TORSION	
200	3-356-672-01	SPRING (PINCH LEVER T), TORSION	
201	3-356-946-01	BUSHING	
202	3-564-121-00	SPRING, COMPRESSION	
203	3-356-713-01	WASHER	
204	3-669-596-00	WASHER (2.3), STOPPER	
HE501	1-543-358-11	HEAD, MAGNETIC (ERASE)	
HRP501	1-543-684-11	HEAD, MAGNETIC (REC/PB)	

5-5. MECHANISM SECTION-2 TCM-200D4



Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
251	X-3362-284-1	FLYWHEEL (S2.3) ASSY		272	3-356-605-01	SPRING, COMPRESSION	
252	X-3356-619-1	FLYWHEEL (DT) ASSY		273	3-356-609-01	GEAR (LOADING)	
253	3-364-600-01	BELT (CAPSTAN)		274	3-356-625-01	SPRING, TENSION	
254	X-3362-281-1	CHASSIS (D2.3) ASSY		275	3-356-653-01	SLIDER (PAUSE)	
255	3-356-705-31	WASHER (CAPSTAN)		276	3-356-616-01	GEAR (LOADING CAM)	
256	3-356-705-21	WASHER (CAPSTAN)		277	* X-3356-606-1	LEVER (LOADING) ASSY	
257	1-632-779-11	PC BOARD, FG		278	3-356-630-01	ROLLER (LOADING)	
258	3-355-801-01	SCREW (BTP 2X18)		279	3-558-708-11	WASHER, STOPPER	
259	* 3-356-628-01	SPACER (MOTOR)		280	3-356-654-01	GEAR (MODE CAM C)	
260	* 1-632-741-11	REEL MOTOR BOARD		281	3-356-617-01	LEVER (SELECTION)	
261	* 1-632-746-11	COMPARATOR BOARD		282	3-356-613-01	LEVER (MODE)	
262	3-364-135-01	RETAINER (S), THRUST		283	A-2006-154-A	CAPSTAN C.O.C BOARD	
263	* 3-701-822-00	HOLDER, WIRE		284	3-356-707-01	SCREW (+PTPH 2X25)	
264	* X-3362-282-1	BRACKET (THRUST RETAINER) ASSY		285	* X-3356-616-4	BRACKET (MOTOR D) ASSY	
265	X-3356-622-1	CHASSIS (C) ASSY, MECHANICAL		286	3-356-631-01	HOLDER (SENSOR)	
266	3-356-703-01	GEAR (COMMUNICATION C)		287	3-363-804-01	SCREW (+P 2.6X6.5)	
267	3-356-607-01	PULLEY (MODE)		288	* 1-632-740-11	MD BOARD	
268	3-356-603-01	BELT (MODE)		IC1001	1-506-615-11	PIN, CONNECTOR 9P	
269	3-356-606-01	GEAR (MODE)		IC1002	1-564-501-11	PIN, CONNECTOR 8P	
270	3-669-465-00	WASHER (1.5), STOPPER		M1001	X-3356-638-1	MOTOR (REEL R) ASSY	
271	3-356-702-01	GEAR (COMMUNICATION B)		M1002	X-3356-604-1	MOTOR (ASSIST) ASSY	
				S1001	1-466-238-11	ENCODER, ROTARY	

CAPSTAN C.O.C

COMPARATOR

MD

SECTION 6

ELECTRICAL PARTS LIST

NOTE :

The components identified by mark Δ or dotted line with mark Δ are critical for safety.
Replace only with part number specified.

When indicating parts by reference number, please include the board name.

- Due to standardization, replacements in the parts list may be different from the parts specified in the diagrams or the components used on the set.
- - XX, - X mean standardized parts, so they may have some difference from the original one.
- RESISTORS
All resistors are in ohms.
METAL : metal-film resistor
METAL OXIDE : Metal Oxide-film resistor
F : nonflammable
- Items marked "*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- SEMICONDUCTORS
In each case, u : μ , for example :
uA... : μ A..., uPA..., μ PA...,
uPB..., μ PB..., uPC..., μ PC...,
uPD..., μ PD...
- CAPACITORS :
uF : μ F
- COILS
uH : μ H

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
	A-2006-154-A	CAPSTAN C. O. C BOARD *****				< IC >	
		< CAPACITOR >		IC951	8-759-945-58	IC RC4558P	
C905	1-124-779-00	ELECT CHIP 10uF 20% 16v		IC952	8-759-201-58	IC TC9142P	
C906	1-135-091-00	TANTALUM CHIP 1uF 20% 16V				< RESISTOR >	
C907	1-163-077-00	CERAMIC CHIP 0.1uF 10% 25V		R951	1-249-413-11	CARBON 470 5% 1/4W	
C908	1-163-077-00	CERAMIC CHIP 0.1uF 10% 25V		R952	1-249-413-11	CARBON 470 5% 1/4W	
C909	1-163-077-00	CERAMIC CHIP 0.1uF 10% 25V		R953	1-247-881-00	CARBON 120K 5% 1/4W	
C910	1-163-205-00	CERAMIC CHIP 0.001uF 5% 50V		R954	1-247-881-00	CARBON 120K 5% 1/4W	
C911	1-124-779-00	ELECT CHIP 10uF 20% 16v		R955	1-249-429-11	CARBON 10K 5% 1/4W	
		< IC >		R956	1-249-417-11	CARBON 1K 5% 1/4W	
H901	8-719-403-79	OH009-TW		R957	1-249-417-11	CARBON 1K 5% 1/4W	
H902	8-719-403-79	OH009-TW		R958	1-247-891-00	CARBON 330K 5% 1/4W	
H903	8-719-403-79	OH009-TW		R959	1-247-901-11	CARBON 820K 5% 1/4W	
IC902	8-752-017-40	IC CX20174		R960	1-249-441-11	CARBON 100K 5% 1/4W	
		< RESISTOR >				< VIBRATOR >	
R907	1-216-242-00	METAL GLAZE 68K 5% 1/8W		X951	1-577-615-11	VIBRATOR, CRYSTAL (4.934MHz)	
R908	1-216-246-00	METAL GLAZE 100K 5% 1/8W				*****	
R909	1-216-246-00	METAL GLAZE 100K 5% 1/8W			* 1-632-740-11	MD BOARD *****	
R910	1-216-238-00	METAL GLAZE 47K 5% 1/8W			3-356-631-01	HOLDER (SENSOR)	
R911	1-216-182-00	METAL GLAZE 220 5% 1/8W				< CONNECTOR >	
R912	1-216-182-00	METAL GLAZE 220 5% 1/8W		CN1001	1-506-615-11	PIN, CONNECTOR 9P	
R913	1-216-150-00	METAL GLAZE 10 5% 1/8W		CN1002	1-564-501-11	PIN, CONNECTOR 8P	
R914	1-216-150-00	METAL GLAZE 10 5% 1/8W				< IC >	
R915	1-216-150-00	METAL GLAZE 10 5% 1/8W		IC1001	8-749-920-97	IC PHOTO REFLECTOR GP2S22B	
		*****		IC1002	8-749-920-97	IC PHOTO REFLECTOR GP2S22B	
	* 1-632-746-11	COMPARATOR BOARD *****				< RESISTOR >	
		< CAPACITOR >		R1001	1-249-408-11	CARBON 180 5% 1/4W	
C951	1-136-157-00	FILM 0.022uF 5% 50V		R1002	1-249-408-11	CARBON 180 5% 1/4W	
C952	1-124-282-00	ELECT 22uF 20% 25V				< SWITCH >	
C953	1-124-478-11	ELECT 100uF 20% 25V		S1002	1-570-953-11	SWITCH, PUSH (1 KEY) (DOOR)	
C954	1-124-477-11	ELECT 47uF 20% 25V		S1003	1-571-958-11	SWITCH, PUSH (1 KEY) (CLOSE)	
C955	1-162-203-31	CERAMIC 15PF 5% 50V		S1004	1-572-126-11	SWITCH, PUSH (1 KEY) (OPEN)	
C956	1-162-203-31	CERAMIC 15PF 5% 50V		S1005	1-572-125-11	SWITCH, LEAF (FWD)	
C957	1-136-159-00	FILM 0.033uF 5% 50V		S1006	1-572-202-11	SWITCH, LEAF (HALF)	
		< CONNECTOR >		S1007	1-572-125-11	SWITCH, LEAF (METAL)	
CN951	* 1-564-718-11	PIN, CONNECTOR (SMALL TYPE) 2P		S1008	1-572-125-11	SWITCH, LEAF (70U)	
CN952	* 1-564-518-11	PLUG, CONNECTOR 3P					

MD		REAL MOTOR		PB		COUNTER		AC SW		TIMER SW	
REC VOL		REC EQ SW		H.P. AMP		PIN JACK		MONITOR SW			
Ref. No.	Part No.	Description			Remark	Ref. No.	Part No.	Description			Remark
< PIN >											
TB1001	* 1-569-066-11	PIN, CONNECTOR 5P									

	* 1-632-741-11	REAL MOTOR BOARD									

< CAPACITOR >											
C1051	1-124-907-11	ELECT	10uF	20%	50V	C116	1-136-173-00	FILM	0.47uF	5%	50V
C1052	1-124-907-11	ELECT	10uF	20%	50V	C117	1-136-167-00	FILM	0.15uF	5%	50V
C1053	1-164-159-11	CERAMIC	0.1uF		50V	C118	1-136-155-00	FILM	0.015uF	5%	50V
< CONNECTOR >											
CN1051	* 1-564-499-11	PIN, CONNECTOR 6P									
CN1052	* 1-564-718-11	PIN, CONNECTOR (SMALL TYPE) 2P									
CN1053	* 1-564-718-11	PIN, CONNECTOR (SMALL TYPE) 2P									
< RESISTOR >											
R1051	1-249-412-11	CARBON	390	5%	1/4W	C121	1-136-163-00	FILM	0.068uF	5%	50V

	* A-2006-364-A	PB BOARD									

	* 1-637-516-11	COUNTER BOARD									

	* 1-637-517-11	AC SW BOARD									

	* 1-637-518-11	TIMER SW BOARD									

	* 1-637-519-11	REC VOL BOARD									

	* 1-637-520-11	REC EQ SW BOARD									

	* 1-637-521-11	H. P. AMP BOARD									

	* 1-637-522-11	PIN JACK BOARD									

	* 1-637-523-11	MONITOR SW BOARD									

	7-682-147-15	SCREW, TR									
	* 3-346-266-21	PLATE, GROUND									
< CAPACITOR >											
C101	1-136-252-00	FILM	0.0015uF	5%	100V	C219	1-123-380-00	ELECT	1uF	20%	50V
C102	1-107-169-00	MICA	100PF	5%	500V	C220	1-136-169-00	FILM	0.22uF	5%	50V
C103	1-130-893-00	FILM	0.027uF	3%	100V	C221	1-136-163-00	FILM	0.068uF	5%	50V
C104	1-124-130-00	ELECT	100uF	20%	63V	C222	1-136-162-00	FILM	0.056uF	5%	50V
C105	1-124-929-11	ELECT	22uF	20%	100V	C223	1-123-380-00	ELECT	1uF	20%	50V
C106	1-124-929-11	ELECT	22uF	20%	100V	C224	1-130-480-00	MYLAR	0.0056uF	5%	50V

PB	COUNTER	AC SW	TIMER SW	REC VOL	REC EQ SW
----	---------	-------	----------	---------	-----------

H.P. AMP	PIN JACK	MONITOR SW
----------	----------	------------

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
C502	1-136-165-00	FILM 0.1uF 5% 50V		D605	8-719-107-94	DIODE 1SS202-1	
C503	1-162-284-31	CERAMIC 150PF 10% 50V		D606	8-719-107-94	DIODE 1SS202-1	
C504	1-130-478-00	MYLAR 0.0039uF 5% 50V		D607	8-719-107-94	DIODE 1SS202-1	
C505	1-124-902-00	ELECT 0.47uF 20% 50V		D608	8-719-107-94	DIODE 1SS202-1	
C506	1-124-927-11	ELECT 4.7uF 20% 100V		D609	8-719-107-94	DIODE 1SS202-1	
C507	1-124-922-11	ELECT 1000uF 20% 63V		D610	8-719-107-94	DIODE 1SS202-1	
C508	1-107-159-00	MICA 33PF 5% 500V		D611	8-719-107-94	DIODE 1SS202-1	
C509	1-126-066-11	ELECT 470uF 20% 63V		D612	8-719-107-94	DIODE 1SS202-1	
C510	1-124-122-11	ELECT 100uF 20% 50V		D613	8-719-107-94	DIODE 1SS202-1	
C511	1-124-922-11	ELECT 1000uF 20% 63V		D614	8-719-107-94	DIODE 1SS202-1	
C512	1-107-159-00	MICA 33PF 5% 500V		D615	8-719-107-94	DIODE 1SS202-1	
C513	1-126-066-11	ELECT 470uF 20% 63V		D616	8-719-107-94	DIODE 1SS202-1	
C514	1-124-122-11	ELECT 100uF 20% 50V		D617	8-719-107-94	DIODE 1SS202-1	
C518	1-124-122-11	ELECT 100uF 20% 50V		D618	8-719-107-94	DIODE 1SS202-1	
C519	1-124-122-11	ELECT 100uF 20% 50V		D619	8-719-107-94	DIODE 1SS202-1	
C601	1-131-368-00	TANTALUM 3.3uF 10% 16V		D620	8-719-107-94	DIODE 1SS202-1	
C603	1-164-159-11	CERAMIC 0.1uF 50V		D881	8-719-304-32	DIODE SEL4214S-C	
C604	1-164-159-11	CERAMIC 0.1uF 50V		D882	8-719-312-65	DIODE SEL4814A-CD	
C606	1-164-159-11	CERAMIC 0.1uF 50V		D883	8-719-304-37	DIODE SEL4414E-C	
C607	1-164-159-11	CERAMIC 0.1uF 50V				< FLUORESCENT INDICATOR >	
C701	1-161-744-00	CERAMIC 0.01uF 400V		FLT601	1-519-629-11	INDICATOR TUBE, FLUORESCENT	
C881	1-124-234-00	ELECT 22uF 20% 16V		FLT881	1-519-630-11	INDICATOR TUBE, FLUORESCENT	
C882	1-126-096-11	ELECT 10uF 20% 35V				< IC >	
C883	1-164-159-11	CERAMIC 0.1uF 50V		IC101	8-759-900-72	IC NE5532P	
		< CONNECTOR >		IC102	8-759-900-72	IC NE5532P	
CN598	* 1-560-061-00	PIN, CONNECTOR 3P		IC201	8-759-900-72	IC NE5532P	
CN599	* 1-560-061-00	PIN, CONNECTOR 3P		IC202	8-759-900-72	IC NE5532P	
CN701	* 1-564-321-00	PIN, CONNECTOR 2P		IC501	8-759-900-72	IC NE5532P	
CN702	* 1-564-321-00	PIN, CONNECTOR 2P		IC502	8-752-018-80	IC CX20188	
CNE501	* 1-564-507-11	PLUG, CONNECTOR 4P		IC503	8-759-945-58	IC RC4558P	
CNE502	* 1-564-511-11	PLUG, CONNECTOR 8P		IC507	8-759-511-57	IC ADJ712JN-SK	
CNE503	* 1-564-509-11	PLUG, CONNECTOR 6P		IC601	8-759-635-68	IC M50940-313SP	
CNE504	* 1-564-507-11	PLUG, CONNECTOR 4P		IC602	8-759-240-69	IC TC4069UBP	
CNE505	* 1-564-506-11	PLUG, CONNECTOR 3P		IC881	8-759-322-98	IC HD404240A31S	
CNN501	* 1-560-062-00	PIN, CONNECTOR 4P		IC882	8-741-100-48	IC SBX1610-59	
CNN502	* 1-560-062-00	PIN, CONNECTOR 4P				< JACK >	
CNN503	* 1-560-062-00	PIN, CONNECTOR 4P		J501	* 1-569-186-11	JACK, PIN 4P (LINE IN/CD DIRECTION)	
CNN504	* 1-560-065-00	PIN, CONNECTOR 8P		J502	* 1-568-250-21	JACK, PIN 2P (LINE OUT)	
CNS501	1-564-104-00	PIN, CONNECTOR 3P		J503	1-507-796-71	JACK (PHONES)	
CNS502	1-564-104-00	PIN, CONNECTOR 3P				< TRANSISTOR >	
		< COMPOSITION >		Q101	8-729-217-03	TRANSISTOR 2SK170-BL	
CP601	1-232-881-11	COMPOSITION CIRCUIT BLOCK		Q102	8-729-217-03	TRANSISTOR 2SK170-BL	
CP602	1-236-985-11	COMPOSITION CIRCUIT BLOCK		Q103	8-729-375-61	TRANSISTOR 2SD660-C	
		< DIODE >		Q104	8-729-201-56	TRANSISTOR 2SK246-GR2	
D501	8-719-107-94	DIODE 1SS202-1		Q105	8-729-194-57	TRANSISTOR 2SC945-P	
D502	8-719-107-94	DIODE 1SS202-1		Q106	8-729-141-30	TRANSISTOR 2SC3623A-LK	
D503	8-719-114-29	DIODE RD5.1JS-B1		Q201	8-729-217-03	TRANSISTOR 2SK170-BL	
D509	8-719-910-65	DIODE HZ6B2L		Q202	8-729-217-03	TRANSISTOR 2SK170-BL	
D510	8-719-910-65	DIODE HZ6B2L		Q203	8-729-375-61	TRANSISTOR 2SD666-C	
D519	8-719-107-94	DIODE 1SS202-1		Q204	8-729-201-56	TRANSISTOR 2SK246-GR2	
D520	8-719-107-94	DIODE 1SS202-1		Q205	8-729-194-57	TRANSISTOR 2SC945-P	
D521	8-719-107-94	DIODE 1SS202-1		Q206	8-729-141-30	TRANSISTOR 2SC3623A-LK	
D524	8-719-107-94	DIODE 1SS202-1		Q501	8-729-900-61	TRANSISTOR DTA114ES	
D601	8-719-107-94	DIODE 1SS202-1		Q502	8-729-900-89	TRANSISTOR DTC144ES	
D602	8-719-107-94	DIODE 1SS202-1		Q503	8-729-900-74	TRANSISTOR DTC143TS	
D603	8-719-107-94	DIODE 1SS202-1					
D604	8-719-107-94	DIODE 1SS202-1					

PB	COUNTER	AC SW	TIMER SW	REC VOL	REC EQ SW
			H.P. AMP	PIN JACK	MONITOR SW

Ref. No.	Part No.	Description	Remark			Ref. No.	Part No.	Description	Remark		
Q504	8-729-620-05	TRANSISTOR	2SC2603-EF			R131	1-247-710-11	CARBON	560	5%	1/4W
Q505	8-729-900-74	TRANSISTOR	DTC143TS			R132	1-246-545-00	CARBON	1.0M	5%	1/4W
Q506	8-729-900-89	TRANSISTOR	DTC144ES			R133	1-249-462-11	CARBON	22K	5%	1/4W
Q507	8-729-119-76	TRANSISTOR	2SA1175-HFE			R134	1-247-152-00	CARBON	7.5K	5%	1/4W
Q508	8-729-900-89	TRANSISTOR	DTC144ES			R135	1-247-711-11	CARBON	680	5%	1/4W
Q509	8-729-107-53	TRANSISTOR	2SC2275A			R136	1-247-154-00	CARBON	9.1K	5%	1/4W
Q510	8-729-375-61	TRANSISTOR	2SD666A			R137	1-249-465-11	CARBON	47K	5%	1/4W
Q511	8-729-375-61	TRANSISTOR	2SD666A			R155	1-247-721-11	CARBON	4.7K	5%	1/4W
Q512	8-729-201-56	TRANSISTOR	2SK246-GR2			R156	1-247-152-00	CARBON	8.2K	5%	1/4W
Q513	8-729-190-53	TRANSISTOR	2SA985A			R157	1-247-725-11	CARBON	10K	5%	1/4W
Q514	8-729-371-61	TRANSISTOR	2SB716			R158	1-247-721-11	CARBON	4.7K	5%	1/4W
Q515	8-729-371-61	TRANSISTOR	2SB716			R159	1-259-500-11	CARBON	1M	5%	1/6W
Q516	8-729-201-56	TRANSISTOR	2SK246-GR2			R160	1-249-462-11	CARBON	22K	5%	1/4W
Q537	8-729-371-61	TRANSISTOR	2SB716			R181	1-247-725-11	CARBON	10K	5%	1/4W
Q538	8-729-375-61	TRANSISTOR	2SD666A			R182	1-249-461-11	CARBON	18K	5%	1/4W
Q601	8-729-900-61	TRANSISTOR	DTA114ES			R183	1-249-469-11	CARBON	100K	5%	1/4W
Q602	8-729-900-61	TRANSISTOR	DTA114ES			R184	1-247-704-11	CARBON	220	5%	1/4W
Q603	8-729-900-65	TRANSISTOR	DTA144ES			R190	1-247-749-11	CARBON	560	5%	1/2W
Q604	8-729-900-65	TRANSISTOR	DTA144ES			R191	1-246-545-00	CARBON	1.0M	5%	1/4W
Q605	8-729-900-65	TRANSISTOR	DTA144ES			R192	1-246-545-00	CARBON	1.0M	5%	1/4W
Q606	8-729-900-65	TRANSISTOR	DTA144ES			R193	1-249-490-11	CARBON	27K	5%	1/2W
Q607	8-729-900-65	TRANSISTOR	DTA144ES			R196	1-215-472-00	METAL	130K	1%	1/6W
Q608	8-729-900-65	TRANSISTOR	DTA144ES			R201	1-249-844-11	CARBON	56K	5%	1/2W
Q609	8-729-900-89	TRANSISTOR	DTC144ES			R202	1-247-128-00	CARBON	750	5%	1/4W
Q610	8-729-900-65	TRANSISTOR	DTA144ES			R203	1-247-128-00	CARBON	750	5%	1/4W
Q611	8-729-900-65	TRANSISTOR	DTA144ES			R204	1-249-504-11	CARBON	10	5%	1/4W
< RESISTOR >						R205	1-247-708-11	CARBON	470	5%	1/4W
R101	1-249-844-11	CARBON	56K	5%	1/2W	R206	1-249-518-11	CARBON	39	5%	1/4W
R102	1-247-128-00	CARBON	750	5%	1/4W	R207	1-247-721-11	CARBON	4.7K	5%	1/4W
R103	1-247-128-00	CARBON	750	5%	1/4W	R208	1-247-704-11	CARBON	220	5%	1/4W
R104	1-249-504-11	CARBON	10	5%	1/4W	R209	1-249-723-11	CARBON	120K	5%	1/2W
R105	1-247-708-11	CARBON	470	5%	1/4W	R210	1-247-255-00	CARBON	4.3K	5%	1/2W
R106	1-249-518-11	CARBON	39	5%	1/4W	R211	1-249-462-11	CARBON	22K	5%	1/4W
R107	1-247-721-11	CARBON	4.7K	5%	1/4W	R212	1-247-740-11	CARBON	120	5%	1/2W
R108	1-247-704-11	CARBON	220	5%	1/4W	R213	1-249-658-11	CARBON	240	5%	1/2W
R109	1-249-723-11	CARBON	120K	5%	1/2W	R214	1-214-851-00	METAL	300	1%	1/2W
R110	1-247-255-00	CARBON	4.3K	5%	1/2W	R215	1-247-764-11	CARBON	10K	5%	1/2W
R111	1-249-462-11	CARBON	22K	5%	1/4W	R216	1-249-429-11	CARBON	10K	5%	1/4W
R112	1-247-740-11	CARBON	120	5%	1/2W	R217	1-247-720-11	CARBON	3.9K	5%	1/4W
R113	1-249-658-11	CARBON	240	5%	1/2W	R218	1-247-718-11	CARBON	2.7K	5%	1/4W
R114	1-214-851-00	METAL	300	1%	1/2W	R219	1-247-718-11	CARBON	2.7K	5%	1/4W
R115	1-247-764-11	CARBON	10K	5%	1/2W	R220	1-247-721-11	CARBON	4.7K	5%	1/4W
R116	1-249-429-11	CARBON	10K	5%	1/4W	R221	1-247-146-00	CARBON	4.3K	5%	1/4W
R117	1-247-720-11	CARBON	3.9K	5%	1/4W	R222	1-247-718-11	CARBON	2.7K	5%	1/4W
R118	1-247-718-11	CARBON	2.7K	5%	1/4W	R223	1-247-718-11	CARBON	2.7K	5%	1/4W
R119	1-247-718-11	CARBON	2.7K	5%	1/4W	R224	1-247-719-11	CARBON	3.3K	5%	1/4W
R120	1-247-721-11	CARBON	4.7K	5%	1/4W	R225	1-249-926-11	CARBON	1.3K	5%	1/4W
R121	1-247-146-00	CARBON	4.3K	5%	1/4W	R226	1-247-891-00	CARBON	330K	5%	1/4W
R122	1-247-718-11	CARBON	2.7K	5%	1/4W	R227	1-247-749-11	CARBON	560	5%	1/2W
R123	1-247-718-11	CARBON	2.7K	5%	1/4W	R228	1-247-764-11	CARBON	10K	5%	1/2W
R124	1-247-719-11	CARBON	3.3K	5%	1/4W	R229	1-247-146-00	CARBON	4.3K	5%	1/4W
R125	1-249-926-11	CARBON	1.3K	5%	1/4W	R230	1-247-142-00	CARBON	3K	5%	1/4W
R126	1-247-891-00	CARBON	330K	5%	1/4W	R231	1-247-710-11	CARBON	560	5%	1/4W
R127	1-247-749-11	CARBON	560	5%	1/2W	R232	1-246-545-00	CARBON	1.0M	5%	1/4W
R128	1-247-764-11	CARBON	10K	5%	1/2W	R233	1-249-462-11	CARBON	22K	5%	1/4W
R129	1-247-146-00	CARBON	4.3K	5%	1/4W	R234	1-247-152-00	CARBON	7.5K	5%	1/4W
R130	1-247-142-00	CARBON	3K	5%	1/4W	R235	1-247-711-11	CARBON	680	5%	1/4W
						R236	1-247-154-00	CARBON	9.1K	5%	1/4W
						R237	1-249-465-11	CARBON	47K	5%	1/4W
						R255	1-247-721-11	CARBON	4.7K	5%	1/4W

PB	COUNTER	AC SW	TIMER SW	REC VOL	REC EQ SW
----	---------	-------	----------	---------	-----------

H.P. AMP	PIN JACK	MONITOR SW
----------	----------	------------

Ref. No.	Part No.	Description	Remark			Ref. No.	Part No.	Description	Remark		
R256	1-247-152-00	CARBON	8. 2K	5%	1/4W	R604	1-247-903-00	CARBON	1M	5%	1/4W
R257	1-247-725-11	CARBON	10K	5%	1/4W	R605	1-247-895-00	CARBON	470K	5%	1/4W
R258	1-247-721-11	CARBON	4. 7K	5%	1/4W	R606	1-249-433-11	CARBON	22K	5%	1/4W
R259	1-259-500-11	CARBON	1M	5%	1/6W	R607	1-249-433-11	CARBON	22K	5%	1/4W
R260	1-249-462-11	CARBON	22K	5%	1/4W	R608	1-249-437-11	CARBON	47K	5%	1/4W
R281	1-247-725-11	CARBON	10K	5%	1/4W	R609	1-249-437-11	CARBON	47K	5%	1/4W
R282	1-249-461-11	CARBON	18K	5%	1/4W	R610	1-249-437-11	CARBON	47K	5%	1/4W
R283	1-249-469-11	CARBON	100K	5%	1/4W	R611	1-249-437-11	CARBON	47K	5%	1/4W
R284	1-247-704-11	CARBON	220	5%	1/4W	R612	1-249-437-11	CARBON	47K	5%	1/4W
R290	1-247-749-11	CARBON	560	5%	1/2W	R613	1-249-437-11	CARBON	47K	5%	1/4W
R291	1-246-545-00	CARBON	1. 0M	5%	1/4W	R614	1-249-421-11	CARBON	2. 2K	5%	1/4W
R292	1-246-545-00	CARBON	1. 0M	5%	1/4W	R615	1-249-421-11	CARBON	2. 2K	5%	1/4W
R293	1-249-490-11	CARBON	27K	5%	1/2W	R616	1-249-429-11	CARBON	10K	5%	1/4W
R321	1-249-824-11	CARBON	8. 2K	5%	1/2W	R617	1-249-437-11	CARBON	47K	5%	1/4W
R322	1-259-500-11	CARBON	1M	5%	1/6W	R618	1-247-842-11	CARBON	3K	5%	1/4W
R323	1-259-436-11	CARBON	2. 2K	5%	1/6W	R619	1-249-426-11	CARBON	5. 6K	5%	1/4W
R421	1-249-824-11	CARBON	8. 2K	5%	1/2W	R620	1-249-437-11	CARBON	47K	5%	1/4W
R422	1-259-500-11	CARBON	1M	5%	1/6W	R621	1-249-421-11	CARBON	2. 2K	5%	1/4W
R423	1-259-436-11	CARBON	2. 2K	5%	1/6W	R622	1-249-421-11	CARBON	2. 2K	5%	1/4W
R501	1-249-434-11	CARBON	27K	5%	1/4W	R699	1-247-764-11	CARBON	10K	5%	1/2W
R502	1-249-429-11	CARBON	10K	5%	1/4W	R881	1-247-903-00	CARBON	1M	5%	1/4W
R503	1-249-425-11	CARBON	4. 7K	5%	1/4W	R882	1-249-433-11	CARBON	22K	5%	1/4W
R504	1-249-433-11	CARBON	22K	5%	1/4W	R883	1-249-425-11	CARBON	4. 7K	5%	1/4W
R506	1-249-429-11	CARBON	10K	5%	1/4W	R884	1-249-425-11	CARBON	4. 7K	5%	1/4W
R507	1-249-417-11	CARBON	1K	5%	1/4W	R885	1-249-422-11	CARBON	2. 7K	5%	1/4W
R508	1-249-435-11	CARBON	33K	5%	1/4W	R886	1-249-424-11	CARBON	3. 9K	5%	1/4W
R509	1-249-429-11	CARBON	10K	5%	1/4W	R887	1-249-422-11	CARBON	2. 7K	5%	1/4W
R510	1-249-425-11	CARBON	4. 7K	5%	1/4W	R888	1-249-424-11	CARBON	3. 9K	5%	1/4W
R511	1-249-417-11	CARBON	1K	5%	1/4W	R889	1-249-428-11	CARBON	8. 2K	5%	1/4W
R512	1-249-434-11	CARBON	27K	5%	1/4W	R890	1-249-434-11	CARBON	27K	5%	1/4W
R513	1-249-429-11	CARBON	10K	5%	1/4W	R891	1-249-422-11	CARBON	2. 7K	5%	1/4W
R514	1-249-441-11	CARBON	100K	5%	1/4W	R892	1-249-424-11	CARBON	3. 9K	5%	1/4W
R515	1-249-417-11	CARBON	1K	5%	1/4W	R893	1-249-428-11	CARBON	8. 2K	5%	1/4W
R516	1-249-433-11	CARBON	22K	5%	1/4W	R894	1-249-434-11	CARBON	27K	5%	1/4W
R517	1-249-431-11	CARBON	15K	5%	1/4W	R895	1-249-424-11	CARBON	3. 9K	5%	1/4W
R518	1-249-429-11	CARBON	10K	5%	1/4W	< VARIABLE RESISTOR >					
R519	1-249-433-11	CARBON	22K	5%	1/4W	RV101	1-224-550-21	RES, ADJ, METAL GLAZE 220			
R521	1-247-749-11	CARBON	560	5%	1/2W	RV201	1-224-550-21	RES, ADJ, METAL GLAZE 220			
R522	1-249-673-11	CARBON	1K	5%	1/2W	RV501	1-230-344-11	RES, VAR, CARBON 20K/20K			
R523	1-247-719-11	CARBON	3. 3K	5%	1/4W	RV502	1-238-840-11	RES, VAR, CARBON 5K/5K			
R524	1-249-547-11	CARBON	620	5%	1/4W	RV503	1-241-336-11	RES, VAR, CARBON 20K/20K			
R525	1-249-466-11	CARBON	56K	5%	1/4W	RV601	1-241-335-11	RES, VAR , CARBON 5K			
R526	1-249-673-11	CARBON	1K	5%	1/2W	< RELAY >					
R527	1-247-749-11	CARBON	560	5%	1/2W	RY503	1-515-803-11	RELAY			
R528	1-247-719-11	CARBON	3. 3K	5%	1/4W	< SWITCH >					
R529	1-249-547-11	CARBON	620	5%	1/4W	S501	1-572-589-11	SWITCH, ROTARY (REC EQ CAL)			
R530	1-249-466-11	CARBON	56K	5%	1/4W	S601	1-572-339-11	SWITCH, PUSH (1 KEY) (HX PRO)			
R570	1-249-433-11	CARBON	22K	5%	1/4W	S602	1-572-339-11	SWITCH, PUSH (1 KEY) (CAL IBRATION)			
R571	1-249-429-11	CARBON	10K	5%	1/4W	S603	1-554-833-11	SWITCH, PUSH (1 KEY) (INPUT:CD/LINE)			
R574	1-249-429-11	CARBON	10K	5%	1/4W	S604	1-572-588-11	SWITCH, ROTARY (DOLBY NR)			
R577	1-247-714-11	CARBON	1. 2K	5%	1/4W	S605	1-572-590-11	SWITCH, ROTARY (MONITOR)			
R578	1-247-704-11	CARBON	220	5%	1/4W	S701	△1-572-267-21	SWITCH, PUSH (AC POWER) (1 KEY) (POWER)			
R579	1-247-714-11	CARBON	1. 2K	5%	1/4W	S881	1-554-303-21	SWITCH, TACTILE (RESET)			
R580	1-247-704-11	CARBON	220	5%	1/4W	S882	1-554-303-21	SWITCH, TACTILE (MEMORY)			
R581	1-247-700-11	CARBON	100	5%	1/4W	S883	1-554-303-21	SWITCH, TACTILE (DISPLAY MODE)			
R582	1-247-700-11	CARBON	100	5%	1/4W						
R599	1-247-764-11	CARBON	10K	5%	1/2W						
R601	1-249-441-11	CARBON	100K	5%	1/4W						
R602	1-249-441-11	CARBON	100K	5%	1/4W						
R603	1-249-425-11	CARBON	4. 7K	5%	1/4W						

Note: The components identified by mark Δ or dotted line with mark Δ are critical for safety. Replace only with part number specified.

PB	COUNTER	AC SW	TIMER SW	REC VOL	REC EQ SW
H.P. AMP			PIN JACK	MONITOR SW	RECT.

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
S884	1-554-303-21	SWITCH, TACTILE (▲)		C155	1-130-485-00	MYLAR 0.015uF 5% 50V	
S885	1-554-303-21	SWITCH, TACTILE (■)		C156	1-136-160-00	FILM 0.039uF 5% 50V	
S886	1-554-303-21	SWITCH, TACTILE (◀)		C157	1-130-486-00	MYLAR 0.018uF 10% 50V	
S887	1-554-303-21	SWITCH, TACTILE (▶)		C159	1-124-929-11	ELECT 22uF 20% 100V	
S888	1-554-303-21	SWITCH, TACTILE (●)		C160	1-136-252-00	FILM 0.0015uF 5% 100V	
S889	1-554-303-21	SWITCH, TACTILE (▶)		C161	1-107-157-00	MICA 27PF 5% 500V	
S890	1-554-303-21	SWITCH, TACTILE (■)		C162	1-107-159-00	MICA 33PF 5% 500V	
S891	1-554-303-21	SWITCH, TACTILE (■)		C163	1-107-169-00	MICA 100PF 5% 500V	
S892	1-554-303-21	SWITCH, TACTILE (■)		C164	1-109-627-00	MICA 150PF 2% 500V	
S893	1-554-303-21	SWITCH, TACTILE (○)		C165	1-109-621-00	MICA 220PF 1% 500V	
S894	1-570-903-11	SWITCH, SLIDE (TIMER)		C166	1-136-153-00	FILM 0.01uF 5% 50V	
		(VIBRATOR)		C167	1-136-163-00	FILM 0.068uF 5% 50V	
X601	1-577-358-21	VIBRATOR, CERAMIC		C168	1-136-157-00	FILM 0.022uF 5% 50V	
X881	1-577-358-21	VIBRATOR, CERAMIC		C170	1-124-925-11	ELECT 2.2uF 20% 100V	
				C171	1-123-382-00	ELECT 3.3uF 20% 100V	
*****				C173	1-124-925-11	ELECT 2.2uF 20% 100V	
	* 1-637-512-11	RECT. BOARD		C174	1-136-165-00	FILM 0.1uF 5% 50V	
		*****		C228	1-123-369-00	ELECT 4.7uF 20% 63V	
	* 1-533-213-31	HOLDER, FUSE		C229	1-123-369-00	ELECT 4.7uF 20% 63V	
	* 3-346-266-12	PLATE, GROUND		C230	1-124-767-00	ELECT 2.2uF 20% 50V	
	* 3-356-925-01	HEAT SINK		C231	1-107-159-00	MICA 33PF 5% 500V	
	* 4-363-146-21	HEAT SINK, V. OUT		C232	1-107-159-00	MICA 33PF 5% 500V	
	7-685-646-79	SCREW +BVTP 3X8 TYPE2 IT-3		C233	1-130-475-00	MYLAR 0.0022uF 5% 50V	
	7-682-547-04	SCREW +BVTT 3X6 (S)		C234	1-130-475-00	MYLAR 0.0022uF 5% 50V	
		(CAPACITOR)		C235	1-130-478-00	MYLAR 0.0039uF 5% 50V	
C128	1-123-369-00	ELECT 4.7uF 20% 63V		C236	1-136-173-00	FILM 0.47uF 5% 50V	
C129	1-123-369-00	ELECT 4.7uF 20% 63V		C237	1-136-167-00	FILM 0.15uF 5% 50V	
C130	1-124-767-00	ELECT 2.2uF 20% 50V		C238	1-136-155-00	FILM 0.015uF 5% 50V	
C131	1-107-159-00	MICA 33PF 5% 500V		C239	1-123-380-00	ELECT 1uF 20% 50V	
C132	1-107-159-00	MICA 33PF 5% 500V		C240	1-136-169-00	FILM 0.22uF 5% 50V	
C133	1-130-475-00	MYLAR 0.0022uF 5% 50V		C241	1-136-163-00	FILM 0.068uF 5% 50V	
C134	1-130-475-00	MYLAR 0.0022uF 5% 50V		C242	1-136-162-00	FILM 0.056uF 5% 50V	
C135	1-130-478-00	MYLAR 0.0039uF 5% 50V		C243	1-123-380-00	ELECT 1uF 20% 50V	
C136	1-136-173-00	FILM 0.47uF 5% 50V		C244	1-130-480-00	MYLAR 0.0056uF 5% 50V	
C137	1-136-167-00	FILM 0.15uF 5% 50V		C245	1-136-153-00	FILM 0.01uF 5% 50V	
C138	1-136-155-00	FILM 0.015uF 5% 50V		C246	1-124-929-11	ELECT 22uF 20% 100V	
C139	1-123-380-00	ELECT 1uF 20% 50V		C247	1-124-929-11	ELECT 22uF 20% 100V	
C140	1-136-169-00	FILM 0.22uF 5% 50V		C250	1-136-252-00	FILM 0.0015uF 5% 100V	
C141	1-136-163-00	FILM 0.068uF 5% 50V		C251	1-124-915-11	ELECT 10uF 20% 63V	
C142	1-136-162-00	FILM 0.056uF 5% 50V		C252	1-136-163-00	FILM 0.068uF 5% 50V	
C143	1-123-380-00	ELECT 1uF 20% 50V		C253	1-130-485-00	MYLAR 0.015uF 5% 50V	
C144	1-130-480-00	MYLAR 0.0056uF 5% 50V		C254	1-136-160-00	FILM 0.039uF 5% 50V	
C145	1-136-153-00	FILM 0.01uF 5% 50V		C255	1-130-485-00	MYLAR 0.015uF 5% 50V	
C146	1-124-929-11	ELECT 22uF 20% 100V		C256	1-136-160-00	FILM 0.039uF 5% 50V	
C147	1-124-929-11	ELECT 22uF 20% 100V		C257	1-130-486-00	MYLAR 0.018uF 10% 50V	
C150	1-136-252-00	FILM 0.0015uF 5% 100V		C259	1-124-929-11	ELECT 22uF 20% 100V	
C151	1-124-915-11	ELECT 10uF 20% 63V		C260	1-136-252-00	FILM 0.0015uF 5% 100V	
C152	1-136-163-00	FILM 0.068uF 5% 50V		C261	1-107-157-00	MICA 27PF 5% 500V	
C153	1-130-485-00	MYLAR 0.015uF 5% 50V		C262	1-107-159-00	MICA 33PF 5% 500V	
C154	1-136-160-00	FILM 0.039uF 5% 50V		C263	1-107-169-00	MICA 100PF 5% 500V	
				C264	1-109-627-00	MICA 150PF 2% 500V	
				C265	1-109-621-00	MICA 220PF 1% 500V	
				C266	1-136-153-00	FILM 0.01uF 5% 50V	
				C267	1-136-163-00	FILM 0.068uF 5% 50V	
				C268	1-136-157-00	FILM 0.022uF 5% 50V	
				C270	1-124-925-11	ELECT 2.2uF 20% 100V	
				C271	1-123-382-00	ELECT 3.3uF 20% 100V	
				C272	1-161-375-00	CERAMIC 0.0022uF 20% 50V	
				C273	1-124-925-11	ELECT 2.2uF 20% 100V	
				C515	1-124-907-11	ELECT 10uF 20% 50V	

RECT.

Ref. No.	Part No.	Description	Remark		
C516	1-123-369-00	ELECT	4.7uF	20%	63V
C517	1-123-369-00	ELECT	4.7uF	20%	63V
C520	1-123-369-00	ELECT	4.7uF	20%	63V
C521	1-124-477-11	ELECT	47uF	20%	25V
C522	1-123-369-00	ELECT	4.7uF	20%	63V
C523	1-124-477-11	ELECT	47uF	20%	25V
C524	1-124-903-11	ELECT	1uF	20%	50V
C525	1-124-907-11	ELECT	10uF	20%	50V
C528	1-107-026-00	MICA	5.1PF		500V
C529	1-124-477-11	ELECT	47uF	20%	25V
C530	1-124-925-11	ELECT	2.2uF	20%	100V
C531	1-124-915-11	ELECT	10uF	20%	63V
C532	1-124-477-11	ELECT	47uF	20%	25V
C533	1-124-915-11	ELECT	10uF	20%	63V
C534	1-124-477-11	ELECT	47uF	20%	25V
C535	1-124-477-11	ELECT	47uF	20%	25V
C536	1-124-477-11	ELECT	47uF	20%	25V
C537	1-130-474-00	MYLAR	0.0018uF	5%	50V
C538	1-130-474-00	MYLAR	0.0018uF	5%	50V
C539	1-136-157-00	FILM	0.022uF	5%	50V
C540	1-136-157-00	FILM	0.022uF	5%	50V
C541	1-124-907-11	ELECT	10uF	20%	50V
C542	1-126-233-11	ELECT	22uF	20%	50V
C543	1-162-217-31	CERAMIC	56PF	5%	50V
C544	1-162-217-31	CERAMIC	56PF	5%	50V
C545	1-124-477-11	ELECT	47uF	20%	25V
C546	1-164-159-11	CERAMIC	0.1uF		50V
C702	1-136-165-00	FILM	0.1uF	5%	50V
C703	1-136-177-00	FILM	1uF	5%	50V
C704	1-126-982-11	ELECT	5600uF	20%	0
C705	1-126-982-11	ELECT	5600uF	20%	0
C706	1-124-636-00	ELECT	3300uF	20%	25V
C707	1-124-120-11	ELECT	220uF	20%	25V
C708	1-124-479-11	ELECT	330uF	20%	25V
C709	1-124-911-11	ELECT	220uF	20%	50V
C710	1-124-767-00	ELECT	2.2uF	20%	50V
C711	1-162-294-31	CERAMIC	0.001uF	10%	50V
C712	1-162-294-31	CERAMIC	0.001uF	10%	50V
C751	1-124-636-00	ELECT	3300uF	20%	25V
C752	1-124-907-11	ELECT	10uF	20%	50V
C753	1-124-122-11	ELECT	100uF	20%	50V
C754	1-124-927-11	ELECT	4.7uF	20%	100V
C755	1-126-101-11	ELECT	100uF	20%	16V
C756	1-124-898-11	ELECT	4700uF	20%	16V
C757	1-124-907-11	ELECT	10uF	20%	50V
C758	1-162-211-31	CERAMIC	33PF	5%	50V
C759	1-124-472-11	ELECT	470uF	20%	10V
C760	1-124-903-11	ELECT	1uF	20%	50V
C761	1-124-471-00	ELECT	1000uF	20%	6.3V
C762	1-124-903-11	ELECT	1uF	20%	50V
C763	1-124-903-11	ELECT	1uF	20%	50V
C764	1-124-443-00	ELECT	100uF	20%	10V
C765	1-124-907-11	ELECT	10uF	20%	50V
C766	1-124-122-11	ELECT	100uF	20%	50V
C767	1-124-443-00	ELECT	100uF	20%	10V
C801	1-164-159-11	CERAMIC	0.1uF		50V
C802	1-164-159-11	CERAMIC	0.1uF		50V
C803	1-124-477-11	ELECT	47uF	20%	25V
C804	1-124-907-11	ELECT	10uF	20%	50V
C805	1-124-443-00	ELECT	100uF	20%	10V



Ref. No.	Part No.	Description	Remark		
C806	1-162-294-31	CERAMIC	0.001uF	10%	50V
C807	1-162-294-31	CERAMIC	0.001uF	10%	50V
< CONNECTOR >					
CN703	* 1-564-104-00	PIN, CONNECTOR 3P			
CN704	* 1-564-506-11	PLUG, CONNECTOR 3P			
CN705	* 1-564-506-11	PLUG, CONNECTOR 3P			
CN751	* 1-564-511-11	PLUG, CONNECTOR 8P			
CN801	* 1-564-336-00	PIN, CONNECTOR 2P			
CN802	* 1-564-341-11	PIN, CONNECTOR 7P			
CN803	* 1-506-503-71	PIN, CONNECTOR 9P			
CN804	* 1-506-503-11	PIN, CONNECTOR 9P			
CN805	* 1-564-339-00	PIN, CONNECTOR 5P			
CN806	* 1-564-666-11	PIN, CONNECTOR 10P			
CN807	* 1-564-342-61	PIN, CONNECTOR 8P			
CN809	* 1-506-503-11	PIN, CONNECTOR 9P			
CND501	* 1-564-340-00	PIN, CONNECTOR 6P			
CND502	* 1-564-341-11	PIN, CONNECTOR 7P			
CNE101	* 1-564-507-11	PLUG, CONNECTOR 4P			
CNE201	* 1-564-507-11	PLUG, CONNECTOR 4P			
CNE504	* 1-564-506-11	PLUG, CONNECTOR 3P			
CNN505	* 1-560-062-00	PIN, CONNECTOR 4P			
CNN506	* 1-560-061-00	PIN, CONNECTOR 3P			
< OSCILLATION UNIT >					
CP501	1-466-252-11	OSCILLATION UNIT, BIAS			
< DIODE >					
D101	8-719-000-60	DIODE UZL-6M2			
D102	8-719-107-94	DIODE 1SS202-1			
D103	8-719-107-94	DIODE 1SS202-1			
D201	8-719-000-60	DIODE UZL-6M2			
D202	8-719-107-94	DIODE 1SS202-1			
D203	8-719-107-94	DIODE 1SS202-1			
D511	8-719-114-29	DIODE RD5.1JS-B1			
D512	8-719-107-94	DIODE 1SS202-1			
D514	8-719-107-94	DIODE 1SS202-1			
D515	8-719-107-94	DIODE 1SS202-1			
D516	8-719-114-29	DIODE RD5.1JS-B1			
D517	8-719-107-94	DIODE 1SS202-1			
D522	8-719-107-94	DIODE 1SS202-1			
D523	8-719-933-41	DIODE HZS6C3L			
D525	8-719-107-94	DIODE 1SS202-1			
D526	8-719-107-94	DIODE 1SS202-1			
D527	8-719-114-29	DIODE RD5.1JS-B1			
D701	8-719-230-02	DIODE 30DF2			
D702	8-719-230-02	DIODE 30DF2			
D703	8-719-230-02	DIODE 30DF2			
D704	8-719-230-02	DIODE 30DF2			
D705	8-719-200-77	DIODE 10E2N			
D706	8-719-200-77	DIODE 10E2N			
D707	8-719-200-77	DIODE 10E2N			
D708	8-719-200-77	DIODE 10E2N			
D709	8-719-200-77	DIODE 10E2N			
D710	8-719-200-77	DIODE 10E2N			
D711	8-719-107-94	DIODE 1SS202-1			
D712	8-719-107-94	DIODE 1SS202-1			
D751	8-719-200-77	DIODE 10E2N			

RECT.

Ref. No.	Part No.	Description	Remark	Ref. No.	Part No.	Description	Remark
D752	8-719-910-25	DIODE HZS12B2L		Q110	8-729-141-30	TRANSISTOR 2SC3623A-LK	
D753	8-719-933-39	DIODE HZS6C1L		Q111	8-729-141-30	TRANSISTOR 2SC3623A-LK	
D754	8-719-933-41	DIODE HZS6C3L		Q112	8-729-900-80	TRANSISTOR DTC114ES	
D755	8-719-933-39	DIODE HZS6C1L		Q113	8-729-900-80	TRANSISTOR DTC114ES	
D756	8-719-002-33	DIODE UZL-24L		Q114	8-729-900-80	TRANSISTOR DTC114ES	
D757	8-719-200-77	DIODE 10E2N		Q116	8-729-141-30	TRANSISTOR 2SC3623A-LK	
D758	8-719-933-39	DIODE HZS6C1L		Q117	8-729-141-30	TRANSISTOR 2SC3623A-LK	
D801	8-719-107-94	DIODE 1SS202-1		Q118	8-729-141-30	TRANSISTOR 2SC3623A-LK	
D802	8-719-107-94	DIODE 1SS202-1		Q207	8-729-142-25	TRANSISTOR 2SD1020-HFE	
		< IC >		Q208	8-729-141-30	TRANSISTOR 2SC3623A-LK	
IC504	8-759-602-83	IC M5238P		Q209	8-729-141-30	TRANSISTOR 2SC3623A-LK	
IC505	8-752-018-80	IC CX20188		Q210	8-729-141-30	TRANSISTOR 2SC3623A-LK	
IC506	8-759-900-72	IC NE5532P		Q211	8-729-141-30	TRANSISTOR 2SC3623A-LK	
IC508	8-759-106-56	IC uPC1297CA		Q212	8-729-900-80	TRANSISTOR DTC114ES	
IC509	8-759-604-86	IC M5F7807		Q213	8-729-900-80	TRANSISTOR DTC114ES	
IC510	8-759-604-90	IC M5F7907		Q214	8-729-900-80	TRANSISTOR DTC114ES	
IC511	8-759-240-50	IC TC4050BP		Q216	8-729-141-30	TRANSISTOR 2SC3623A-LK	
IC512	8-759-602-83	IC M5238P		Q217	8-729-141-30	TRANSISTOR 2SC3623A-LK	
IC513	8-759-945-58	IC RC4558P		Q218	8-729-141-30	TRANSISTOR 2SC3623A-LK	
IC514	8-759-634-51	IC M5218AP		Q517	8-729-900-61	TRANSISTOR DTA114ES	
IC515	8-759-945-58	IC RC4558P		Q518	8-729-281-53	TRANSISTOR 2SC1815-GR	
IC518	8-759-982-26	IC RC78L12A		Q519	8-729-119-76	TRANSISTOR 2SA1175-HFE	
IC519	8-759-982-48	IC RC79L12A		Q520	8-729-900-36	TRANSISTOR DTC124ES	
IC801	8-759-635-69	IC M50964-226SP		Q522	8-729-141-30	TRANSISTOR 2SC3623ATP-LK	
IC802	8-759-973-95	IC BA6219B		Q523	8-729-141-30	TRANSISTOR 2SC3623ATP-LK	
IC803	8-759-822-09	IC LB1641		Q524	8-729-141-30	TRANSISTOR 2SC3623ATP-LK	
		< COIL >		Q529	8-729-141-30	TRANSISTOR 2SC3623ATP-LK	
L101	1-408-920-00	INDUCTOR 4.7mH		Q530	8-729-141-30	TRANSISTOR 2SC3623ATP-LK	
L102	1-408-918-11	INDUCTOR 3.3mH		Q533	8-729-900-36	TRANSISTOR DTC124ES	
L103	1-408-916-11	INDUCTOR 2.2mH		Q534	8-729-900-74	TRANSISTOR DTC143TS	
L104	1-408-925-11	INDUCTOR 12mH		Q535	8-729-900-36	TRANSISTOR DTC124ES	
L105	1-408-916-11	INDUCTOR 2.2mH		Q536	8-729-900-36	TRANSISTOR DTC124ES	
L201	1-408-920-00	INDUCTOR 4.7mH		Q539	8-729-900-36	TRANSISTOR DTC124ES	
L202	1-408-918-11	INDUCTOR 3.3mH		Q540	8-729-620-05	TRANSISTOR 2SC2603-EF	
L203	1-408-916-11	INDUCTOR 2.2mH		Q701	8-729-620-05	TRANSISTOR 2SC2603-EF	
L204	1-408-925-11	INDUCTOR 12mH		Q751	8-729-924-90	TRANSISTOR 2SB1370-EF	
L205	1-408-916-11	INDUCTOR 2.2mH		Q752	8-729-924-90	TRANSISTOR 2SB1370-EF	
L501	1-410-525-11	INDUCTOR 220uH		Q753	8-729-111-55	TRANSISTOR 2SD2061-EF	
L502	1-410-525-11	INDUCTOR 220uH		Q754	8-729-119-76	TRANSISTOR 2SA1175-HFE	
L503	1-410-525-11	INDUCTOR 220uH		Q755	8-729-140-97	TRANSISTOR 2SB734-34	
		< PILOT LAMP >		Q756	8-729-620-05	TRANSISTOR 2SC2603-EF	
LP501	1-518-471-31	LAMP, PILOT		Q757	8-729-620-05	TRANSISTOR 2SC2603-EF	
LP502	1-518-471-31	LAMP, PILOT		Q758	8-729-620-05	TRANSISTOR 2SC2603-EF	
		< FILTER >		Q759	8-729-620-05	TRANSISTOR 2SC2603-EF	
LPF101	1-236-087-11	FILTER, LOW PASS		Q801	8-729-119-76	TRANSISTOR 2SA1175-HFE	
LPF201	1-236-087-11	FILTER, LOW PASS		Q802	8-729-119-76	TRANSISTOR 2SA1175-HFE	
		< IC LINK >		Q803	8-729-620-05	TRANSISTOR 2SC2603-EF	
PS701	1-532-685-00	LINK, IC		Q804	8-729-620-05	TRANSISTOR 2SC2603-EF	
PS702	1-532-685-00	LINK, IC		Q805	8-729-900-61	TRANSISTOR DTA114ES	
		< TRANSISTOR >		Q806	8-729-900-61	TRANSISTOR DTA114ES	
Q107	8-729-142-25	TRANSISTOR 2SD1020TP-HFE		Q807	8-729-900-61	TRANSISTOR DTA114ES	
Q108	8-729-141-30	TRANSISTOR 2SC3623A-LK		Q808	8-729-900-61	TRANSISTOR DTA114ES	
Q109	8-729-141-30	TRANSISTOR 2SC3623A-LK		Q809	8-729-900-65	TRANSISTOR DTA144ES	
				Q810	8-729-900-65	TRANSISTOR DTA144ES	
				Q811	8-729-900-65	TRANSISTOR DTA144ES	
				Q812	8-729-900-65	TRANSISTOR DTA144ES	
				Q813	8-729-900-65	TRANSISTOR DTA144ES	
				Q814	8-729-900-65	TRANSISTOR DTA144ES	
				Q815	8-729-900-61	TRANSISTOR DTA114ES	
				Q816	8-729-900-61	TRANSISTOR DTA114ES	

RECT.

Ref. No.	Part No.	Description	Remark			Ref. No.	Part No.	Description	Remark		
< RESISTOR >						R249	1-246-545-00	CARBON	1.0M	5%	1/4W
R138	1-249-469-11	CARBON	100K	5%	1/4W	R250	1-249-462-11	CARBON	22K	5%	1/4W
R139	1-247-723-11	CARBON	6.8K	5%	1/4W	R251	1-247-152-00	CARBON	7.5K	5%	1/4W
R140	1-247-720-11	CARBON	3.9K	5%	1/4W	R252	1-247-711-11	CARBON	680	5%	1/4W
R141	1-247-719-11	CARBON	3.3K	5%	1/4W	R253	1-247-154-00	CARBON	9.1K	5%	1/4W
R142	1-247-152-00	CARBON	7.5K	5%	1/4W	R254	1-249-465-11	CARBON	47K	5%	1/4W
R143	1-249-469-11	CARBON	100K	5%	1/4W	R261	1-247-719-11	CARBON	3.3K	5%	1/4W
R144	1-247-747-11	CARBON	470	5%	1/2W	R262	1-247-723-11	CARBON	6.8K	5%	1/4W
R145	1-247-764-11	CARBON	10K	5%	1/2W	R263	1-249-590-11	CARBON	39K	5%	1/4W
R146	1-247-146-00	CARBON	4.3K	5%	1/4W	R264	1-249-425-11	CARBON	4.7K	5%	1/4W
R147	1-247-142-00	CARBON	3K	5%	1/4W	R265	1-249-429-11	CARBON	10K	5%	1/4W
R148	1-247-710-11	CARBON	560	5%	1/4W	R266	1-249-465-11	CARBON	47K	5%	1/4W
R149	1-246-545-00	CARBON	1.0M	5%	1/4W	R267	1-247-716-11	CARBON	1.8K	5%	1/4W
R150	1-249-462-11	CARBON	22K	5%	1/4W	R268	1-249-598-11	CARBON	82K	5%	1/4W
R151	1-247-152-00	CARBON	7.5K	5%	1/4W	R269	1-259-467-11	CARBON	43K	5%	1/4W
R152	1-247-711-11	CARBON	680	5%	1/4W	R270	1-247-702-11	CARBON	150	5%	1/4W
R153	1-247-154-00	CARBON	9.1K	5%	1/4W	R271	1-247-154-00	CARBON	9.1K	5%	1/4W
R154	1-249-465-11	CARBON	47K	5%	1/4W	R272	1-249-429-11	CARBON	10K	5%	1/4W
R161	1-247-719-11	CARBON	3.3K	5%	1/4W	R273	1-247-701-11	CARBON	120	5%	1/4W
R162	1-247-723-11	CARBON	6.8K	5%	1/4W	R274	1-247-142-00	CARBON	3K	5%	1/4W
R163	1-249-590-11	CARBON	39K	5%	1/4W	R275	1-247-721-11	CARBON	4.7K	5%	1/4W
R164	1-249-425-11	CARBON	4.7K	5%	1/4W	R276	1-249-429-11	CARBON	10K	5%	1/4W
R165	1-249-429-11	CARBON	10K	5%	1/4W	R277	1-247-700-11	CARBON	100	5%	1/4W
R166	1-249-465-11	CARBON	47K	5%	1/4W	R278	1-247-719-11	CARBON	3.3K	5%	1/4W
R167	1-247-716-11	CARBON	1.8K	5%	1/4W	R279	1-247-719-11	CARBON	3.3K	5%	1/4W
R168	1-249-598-11	CARBON	82K	5%	1/4W	R280	1-249-429-11	CARBON	10K	5%	1/4W
R169	1-259-467-11	CARBON	43K	5%	1/4W	R285	1-247-718-11	CARBON	2.7K	5%	1/4W
R170	1-247-702-11	CARBON	150	5%	1/4W	R286	1-247-883-00	CARBON	150K	5%	1/4W
R171	1-247-154-00	CARBON	9.1K	5%	1/4W	R287	1-247-714-11	CARBON	1.2K	5%	1/4W
R172	1-249-429-11	CARBON	10K	5%	1/4W	R288	1-247-714-11	CARBON	1.2K	5%	1/4W
R173	1-247-701-11	CARBON	120	5%	1/4W	R289	1-249-425-11	CARBON	4.7K	5%	1/4W
R174	1-247-142-00	CARBON	3K	5%	1/4W	R294	1-247-883-00	CARBON	150K	5%	1/4W
R175	1-247-721-11	CARBON	4.7K	5%	1/4W	R295	1-249-417-11	CARBON	1K	5%	1/4W
R176	1-249-429-11	CARBON	10K	5%	1/4W	R296	1-215-472-00	METAL	130K	1%	1/6W
R177	1-247-700-11	CARBON	100	5%	1/4W	R297	1-249-408-11	CARBON	180	5%	1/4W
R178	1-247-719-11	CARBON	3.3K	5%	1/4W	R298	1-249-414-11	CARBON	560	5%	1/4W
R179	1-247-719-11	CARBON	3.3K	5%	1/4W	R299	1-249-417-11	CARBON	1K	5%	1/4W
R180	1-249-429-11	CARBON	10K	5%	1/4W	R301	1-249-428-11	CARBON	8.2K	5%	1/4W
R185	1-247-718-11	CARBON	2.7K	5%	1/4W	R302	1-249-417-11	CARBON	1K	5%	1/4W
R186	1-247-883-00	CARBON	150K	5%	1/4W	R303	1-247-725-11	CARBON	10K	5%	1/4W
R187	1-247-714-11	CARBON	1.2K	5%	1/4W	R304	1-249-429-11	CARBON	10K	5%	1/4W
R188	1-247-714-11	CARBON	1.2K	5%	1/4W	R305	1-249-429-11	CARBON	10K	5%	1/4W
R189	1-249-425-11	CARBON	4.7K	5%	1/4W	R306	1-249-417-11	CARBON	1K	5%	1/4W
R194	1-247-883-00	CARBON	150K	5%	1/4W	R307	1-249-437-11	CARBON	47K	5%	1/4W
R195	1-249-417-11	CARBON	1K	5%	1/4W	R308	1-215-465-00	METAL	68K	1%	1/6W
R197	1-249-408-11	CARBON	180	5%	1/4W	R309	1-215-474-00	METAL	160K	1%	1/6W
R198	1-249-414-11	CARBON	560	5%	1/4W	R310	1-215-448-00	METAL	13K	1%	1/6W
R199	1-249-417-11	CARBON	1K	5%	1/4W	R311	1-249-408-11	CARBON	180	5%	1/4W
R238	1-249-469-11	CARBON	100K	5%	1/4W	R312	1-247-883-00	CARBON	150K	5%	1/4W
R239	1-247-723-11	CARBON	6.8K	5%	1/4W	R314	1-249-423-11	CARBON	3.3K	5%	1/4W
R240	1-247-720-11	CARBON	3.9K	5%	1/4W	R316	1-249-425-11	CARBON	4.7K	5%	1/4W
R241	1-247-719-11	CARBON	3.3K	5%	1/4W	R317	1-249-429-11	CARBON	10K	5%	1/4W
R242	1-247-152-00	CARBON	7.5K	5%	1/4W	R318	1-249-616-11	CARBON	470K	5%	1/4K
R243	1-249-469-11	CARBON	100K	5%	1/4W	R319	△1-212-857-00	FUSIBLE	10	5%	1/4W F
R244	1-247-747-11	CARBON	470	5%	1/2W	R320	1-249-465-11	CARBON	47K	5%	1/4W
R245	1-247-764-11	CARBON	10K	5%	1/2W	R401	1-249-428-11	CARBON	8.2K	5%	1/4W
R246	1-247-146-00	CARBON	4.3K	5%	1/4W	R402	1-249-417-11	CARBON	1K	5%	1/4W
R247	1-247-142-00	CARBON	3K	5%	1/4W	R403	1-247-725-11	CARBON	10K	5%	1/4W
R248	1-247-710-11	CARBON	560	5%	1/4W	R404	1-249-429-11	CARBON	10K	5%	1/4W
						R405	1-249-429-11	CARBON	10K	5%	1/4W

Note: The components identified by mark  or dotted line with mark  are critical for safety. Replace only with part number specified.

RECT.

Ref. No.	Part No.	Description	Remark			Ref. No.	Part No.	Description	Remark		
R406	1-249-417-11	CARBON	1K	5%	1/4W	R754	1-249-437-11	CARBON	47K	5%	1/4W
R407	1-249-437-11	CARBON	47K	5%	1/4W	R755	1-249-421-11	CARBON	2. 2K	5%	1/4W
R408	1-215-465-00	METAL	68K	1%	1/6W	R756	1-249-425-11	CARBON	4. 7K	5%	1/4W
R409	1-215-474-00	METAL	160K	1%	1/6W	R757	1-249-437-11	CARBON	47K	5%	1/4W
R410	1-215-448-00	METAL	13K	1%	1/6W	R758	1-249-422-11	CARBON	2. 7K	5%	1/4W
R411	1-249-408-11	CARBON	180	5%	1/4W	R759	1-249-427-11	CARBON	6. 8K	5%	1/4W
R412	1-247-883-00	CARBON	150K	5%	1/4W	R760	1-249-425-11	CARBON	4. 7K	5%	1/4W
R414	1-249-423-11	CARBON	3. 3K	5%	1/4W	R761	1-249-437-11	CARBON	47K	5%	1/4W
R416	1-249-425-11	CARBON	4. 7K	5%	1/4W	R762	1-249-421-11	CARBON	2. 2K	5%	1/4W
R417	1-249-429-11	CARBON	10K	5%	1/4W	R763	1-249-441-11	CARBON	100K	5%	1/4W
R418	1-249-616-11	CARBON	470K	5%	1/4W	R764	1-249-425-11	CARBON	4. 7K	5%	1/4W
R419	△1-212-857-00	FUSIBLE	10	5%	1/4W	R765	1-249-437-11	CARBON	47K	5%	1/4W
R420	1-249-465-11	CARBON	47K	5%	1/4W	R766	1-249-437-11	CARBON	47K	5%	1/4W
R531	1-249-438-11	CARBON	56K	5%	1/4W	R767	1-249-429-11	CARBON	10K	5%	1/4W
R532	1-249-433-11	CARBON	22K	5%	1/4W	R768	1-249-437-11	CARBON	47K	5%	1/4W
R533	1-249-421-11	CARBON	2. 2K	5%	1/4W	R769	1-249-437-11	CARBON	47K	5%	1/4W
R537	1-249-417-11	CARBON	1K	5%	1/4W	R770	1-249-433-11	CARBON	22K	5%	1/4W
R538	1-249-425-11	CARBON	4. 7K	5%	1/4W	R771	1-249-395-11	CARBON	15	5%	1/4W
R539	1-249-437-11	CARBON	47K	5%	1/4W	R772	1-249-395-11	CARBON	15	5%	1/4W
R540	1-249-433-11	CARBON	22K	5%	1/4W	R773	△1-219-136-11	FUSIBLE	0. 22	10%	1/4W
R542	1-249-429-11	CARBON	10K	5%	1/4W	R774	△1-219-136-11	FUSIBLE	0. 22	10%	1/4W
R543	1-249-424-11	CARBON	3. 9K	5%	1/4W	R775	△1-219-136-11	FUSIBLE	0. 22	10%	1/4W
R544	1-249-418-11	CARBON	1. 2K	5%	1/4W	R776	1-249-413-11	CARBON	470	5%	1/4W
R545	1-249-428-11	CARBON	8. 2K	5%	1/4W	R801	△1-249-482-11	CARBON	4. 7	5%	1/2W F
R546	1-249-429-11	CARBON	10K	5%	1/4W	R802	1-249-425-11	CARBON	4. 7K	5%	1/4W
R547	1-249-405-11	CARBON	100	5%	1/4W	R803	1-249-425-11	CARBON	4. 7K	5%	1/4W
R548	1-249-405-11	CARBON	100	5%	1/4W	R804	1-249-426-11	CARBON	5. 6K	5%	1/4W
R549	1-249-405-11	CARBON	100	5%	1/4W	R805	1-247-856-00	CARBON	11K	5%	1/4W
R550	1-249-405-11	CARBON	100	5%	1/4W	R806	1-249-425-11	CARBON	4. 7K	5%	1/4W
R551	1-249-405-11	CARBON	100	5%	1/4W	R807	△1-249-482-11	CARBON	4. 7	5%	1/2W F
R552	1-249-405-11	CARBON	100	5%	1/4W	R808	1-249-425-11	CARBON	4. 7K	5%	1/4W
R553	1-249-429-11	CARBON	10K	5%	1/4W	R809	1-249-425-11	CARBON	4. 7K	5%	1/4W
R554	1-249-429-11	CARBON	10K	5%	1/4W	R810	1-249-426-11	CARBON	5. 6K	5%	1/4W
R556	1-249-428-11	CARBON	8. 2K	5%	1/4W	R811	1-249-429-11	CARBON	10K	5%	1/4W
R557	1-247-856-00	CARBON	11K	5%	1/4W	R812	1-249-425-11	CARBON	4. 7K	5%	1/4W
R558	1-249-397-11	CARBON	22	5%	1/4W	R813	1-249-429-11	CARBON	10K	5%	1/4W
R559	1-249-407-11	CARBON	150	5%	1/4W	R814	1-249-429-11	CARBON	10K	5%	1/4W
R560	1-247-856-00	CARBON	11K	5%	1/4W	R815	1-249-429-11	CARBON	10K	5%	1/4W
R561	1-249-428-11	CARBON	8. 2K	5%	1/4W	R816	1-249-429-11	CARBON	10K	5%	1/4W
R562	1-249-432-11	CARBON	18K	5%	1/4W	R817	1-249-429-11	CARBON	10K	5%	1/4W
R563	1-249-397-11	CARBON	22	5%	1/4W	R818	1-249-429-11	CARBON	10K	5%	1/4W
R564	1-249-407-11	CARBON	150	5%	1/4W	R819	1-249-429-11	CARBON	10K	5%	1/4W
R565	1-249-432-11	CARBON	18K	5%	1/4W	R820	1-249-429-11	CARBON	10K	5%	1/4W
R566	1-247-887-00	CARBON	220K	5%	1/4W	R821	1-249-429-11	CARBON	10K	5%	1/4W
R567	1-247-887-00	CARBON	220K	5%	1/4W	R822	1-249-429-11	CARBON	10K	5%	1/4W
R568	1-249-407-11	CARBON	150	5%	1/4W	R823	1-249-429-11	CARBON	10K	5%	1/4W
R569	1-249-422-11	CARBON	2. 7K	5%	1/4W	R824	1-249-405-11	CARBON	100	5%	1/4W
R572	1-249-429-11	CARBON	10K	5%	1/4W	R825	1-249-405-11	CARBON	100	5%	1/4W
R573	1-249-439-11	CARBON	68K	5%	1/4W	R826	1-249-405-11	CARBON	100	5%	1/4W
R575	1-249-429-11	CARBON	10K	5%	1/4W	R827	1-249-405-11	CARBON	100	5%	1/4W
R576	1-249-429-11	CARBON	10K	5%	1/4W	R828	1-249-405-11	CARBON	100	5%	1/4W
R583	1-249-417-11	CARBON	1K	5%	1/4W	R829	1-249-405-11	CARBON	100	5%	1/4W
R584	1-249-437-11	CARBON	47K	5%	1/4W	R830	1-249-405-11	CARBON	100	5%	1/4W
R587	1-249-437-11	CARBON	47K	5%	1/4W	R831	1-249-405-11	CARBON	100	5%	1/4W
R701	△1-212-861-11	FUSIBLE	15	5%	1/4W	R832	1-249-405-11	CARBON	100	5%	1/4W
R702	1-249-436-11	CARBON	39K	5%	1/4W	R833	1-249-405-11	CARBON	100	5%	1/4W
R703	1-249-439-11	CARBON	68K	5%	1/4W	R834	1-249-405-11	CARBON	100	5%	1/4W
R751	1-249-421-11	CARBON	2. 2K	5%	1/4W	R835	1-249-425-11	CARBON	4. 7K	5%	1/4W
R752	1-249-425-11	CARBON	4. 7K	5%	1/4W	R836	1-249-417-11	CARBON	1K	5%	1/4W
R753	1-249-437-11	CARBON	47K	5%	1/4W	R837	1-249-435-11	CARBON	33K	5%	1/4W

Note: The components identified by mark **△** or dotted line with mark **△** are critical for safety. Replace only with part number specified.

RECT.

Ref. No.	Part No.	Description	Remark		
R838	1-249-435-11	CARBON	33K	5%	1/4W
R839	1-247-903-00	CARBON	1M	5%	1/4W
R840	1-249-429-11	CARBON	10K	5%	1/4W
R841	1-249-405-11	CARBON	100	5%	1/4W
R842	1-249-405-11	CARBON	100	5%	1/4W
R843	1-249-405-11	CARBON	100	5%	1/4W
R844	1-249-405-11	CARBON	100	5%	1/4W
R845	1-249-429-11	CARBON	10K	5%	1/4W
R846	1-249-429-11	CARBON	10K	5%	1/4W
R847	1-249-427-11	CARBON	6.8K	5%	1/4W
R848	1-249-429-11	CARBON	10K	5%	1/4W
R849	1-249-429-11	CARBON	10K	5%	1/4W
R850	1-249-429-11	CARBON	10K	5%	1/4W
R851	1-249-429-11	CARBON	10K	5%	1/4W
R852	1-249-413-11	CARBON	470	5%	1/4W
R853	1-249-412-11	CARBON	390	5%	1/4W
R854	1-249-410-11	CARBON	270	5%	1/4W
R855	1-249-436-11	CARBON	39K	5%	1/4W
R856	1-249-436-11	CARBON	39K	5%	1/4W
R857	1-249-405-11	CARBON	100	5%	1/4W
R858	1-249-405-11	CARBON	100	5%	1/4W
R859	1-249-405-11	CARBON	100	5%	1/4W
R860	1-249-405-11	CARBON	100	5%	1/4W
R861	1-249-429-11	CARBON	10K	5%	1/4W
R862	1-249-429-11	CARBON	10K	5%	1/4W
R863	1-249-441-11	CARBON	100K	5%	1/4W
R864	1-249-441-11	CARBON	100K	5%	1/4W
R865	1-249-441-11	CARBON	100K	5%	1/4W
R866	1-249-441-11	CARBON	100K	5%	1/4W
R867	1-249-441-11	CARBON	100K	5%	1/4W
R868	1-249-441-11	CARBON	100K	5%	1/4W
< VARIABLE RESISTOR >					
RV102	1-224-251-XX	RES, ADJ, METAL GLAZE	4.7K		
RV103	1-238-011-11	RES, ADJ, CARBON	470		
RV104	1-238-597-11	RES, ADJ, CARBON	1K		
RV105	1-238-600-11	RES, ADJ, CARBON	10K		
RV106	1-238-600-11	RES, ADJ, CARBON	10K		
RV107	1-238-600-11	RES, ADJ, CARBON	10K		
RV108	1-238-601-11	RES, ADJ, CARBON	22K		
RV202	1-224-251-XX	RES, ADJ, METAL GLAZE	4.7K		
RV203	1-238-011-11	RES, ADJ, CARBON	470		
RV204	1-238-597-11	RES, ADJ, CARBON	1K		
RV205	1-238-600-11	RES, ADJ, CARBON	10K		
RV206	1-238-600-11	RES, ADJ, CARBON	10K		
RV207	1-238-600-11	RES, ADJ, CARBON	10K		
RV208	1-238-601-11	RES, ADJ, CARBON	22K		
RV504	1-241-231-11	RES, ADJ, CARBON	100		
RV505	1-241-231-11	RES, ADJ, CARBON	100		
RV801	1-238-598-11	RES, ADJ, CARBON	2.2K		
< RELAY >					
RY502	1-515-803-11	RELAY			
RY503	1-515-614-11	RELAY			
< TRANSFORMER >					
T101	1-433-361-11	TRANSFORMER, BIAS OSCILLATION			
T201	1-433-361-11	TRANSFORMER, BIAS OSCILLATION			

Ref. No.	Part No.	Description	Remark
		< THERMISTOR >	
TH501	1-202-855-00	THERMISTOR (POSITIVE)	
		< TEST PIN >	
TP1	* 1-535-115-00	TERMINAL	
TP801	* 1-564-337-00	PIN, CONNECTOR 3P	
		< VIBRATOR >	
X801	1-577-358-21	VIBRATOR, CERAMIC	

		MISCELLANEOUS	

112	1-559-297-32	CORD, POWER (K333ESL:E)	
112	1-574-383-11	CORD, POWER (K970ES)	
119	1-569-007-11	ADAPTER, CONVERSION 2P (K333ESL:E)	
196	* 1-608-268-00	PC BOARD, ERASE HEAD	
257	1-632-779-11	PC BOARD, FG	
F701	1-532-286-00	FUSE, TIME-LAG (2.5A)	
F702	1-532-286-00	FUSE, TIME-LAG (2.5A)	
HE501	1-543-358-11	HEAD, MAGNETIC (ERASE)	
HRP501	1-543-684-11	HEAD, MAGNETIC (REC/PB)	
M1001	X-3356-638-1	MOTOR (REEL R) ASSY	
M1002	X-3356-604-1	MOTOR (ASSIST) ASSY	
S1001	1-466-238-11	ENCODER, ROTARY	
S702	1-157-009-11	SELECTOR, VOLTAGE	
T701	△1-450-451-11	TRANSFORMER, POWER (K970ES)	
T701	△1-450-453-11	TRANSFORMER, POWER (K333ESL:E)	

		ACCESSORY & PACKING MATERIAL	

	1-465-314-11	REMOTE COMMANDER (K333ESL:E)	
	2-181-754-01	COVER, BATTERY (K333ESL:E)	
	1-558-271-11	CORD, CONNECTION	
	* 3-350-465-01	CUSHION	
	* 3-367-121-01	INDIVIDUAL CARTON (K970ES)	
	* 3-367-122-01	INDIVIDUAL CARTON (K333ESL:E)	
	3-367-548-11	LABEL, MODEL NUMBER (AE)	
	3-752-611-11	MANUAL, INSTRUCTION (English, French, Spanish, Portuguese)	
	3-752-611-41	MANUAL, INSTRUCTION (K970ES: German, Dutch, Swedish, Italian)	
	3-793-481-13	INSTRUCTION	
	4-847-802-00	SCREW	

<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>	<u>Remark</u>
HARDWARE LIST			

# 1	7-682-547-04	SCREW +BVTT 3X6 (S)	
# 2	7-682-562-09	SCREW +BVTT 4X10 (S)	
# 3	7-682-548-04	SCREW, TIGHT, S	
# 4	7-685-870-01	SCREW +BVTT 3X5 (S)	
# 5	7-682-547-09	SCREW +BV 3X6, S TIGHT	
# 6	7-685-645-79	SCREW +BVTP 3X6 TYPE2 SLIT	
# 7	7-682-549-04	SCREW +BVTT 3X10 (S)	
# 8	7-682-147-15	SCREW, TR	
# 9	7-685-647-79	SCREW +BVTP 3X10 TYPE2 N-S	
# 10	7-682-560-04	SCREW +BVTT 4X6 (S) (K333ESL:E)	
# 11	7-621-772-10	SCREW +B 2X4	
# 12	7-621-772-70	SCREW +B 2X14	
# 13	7-621-775-10	SCREW +B 2.6X4	
# 14	7-622-205-05	NUT M2 TYPE2	
# 15	7-628-253-00	SCREW +PS 2X4	
# 16	7-628-254-10	SCREW +PS 2.6X6	
# 17	7-671-154-01	STENLESS BALL	
# 18	7-682-648-09	SCREW +PS 3X8	
# 19	7-685-133-19	SCREW +BTP 2.6X6 TYPE2 N-S	
# 20	7-621-255-20	SCREW +BVTT 2X4 (S)	
# 21	7-621-255-35	SCREW +BVTT 2X5 (S)	
# 22	7-685-870-01	SCREW +BVTT 3X5 (S)	

TC-K333ESL/K970ES

SONY[®] SERVICE MANUAL

AEP Model
TC-K970ES

E Model
TC-K333ESL

SUPPLEMENT-1

File this Supplement with the Service Manual.

Subject : The gold type of TC-K970ES has been added.

- The gold type is the same as black type except for the parts as shown in the table.
- Use this manual for servicing the gold-type set.
- Items marked "*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.

page	BLACK TYPE		GOLD TYPE	
	Ref. No	Part. No	Part. No	Description
43	2	3-364-438-21	3-364-438-31	WINDOW, CASSETTE
	4	X-3362-818-1	X-3363-490-1	KNOB (DIA, 12) ASSY (B), SQUARE
	5	3-364-475-31	3-364-475-41	PANEL, FRONT
	7	4-908-848-01	4-908-848-21	EMBLEM, SONY
	8	4-908-044-11	4-908-044-21	ESCUTCHEON, POWER KNOB
	9	3-364-444-01	4-908-444-11	ESCUTCHEON (L)
	10	3-364-442-11	3-364-442-21	WINDOW, COUNTER
	12	3-364-443-01	3-364-443-11	WINDOW, METER
	13	3-364-447-01	3-364-447-11	ESCUTCHEON (R)
	15	X-3304-959-1	X-3363-492-2	PANEL (LEFT) ASSY, SIDE
	16	4-923-474-01	4-928-025-41	RING, ORNAMENTAL
	17	3-704-366-01	3-704-366-11	SCREW (CASE) (M3 × 8)
	18	*3-350-489-11	*3-350-489-21	CASE
	19	X-3304-960-1	X-3363-493-2	PANEL (RIGHT) ASSY, SIDE
	21	X-3304-944-1	X-3363-489-1	FOOT ASSY
44	51	*3-364-474-01	*3-364-474-12	PANEL (BASE)
	52	4-922-518-11	4-922-518-62	KNOB (TIMER)
	53	4-908-046-01	4-908-046-81	KNOB, SQUARE
	64	X-3362-327-1	X-3363-491-1	BUTTON ASSY
	70	3-364-441-01	3-364-441-11	BUTTON
	71	3-364-440-01	3-364-440-11	KNOB (L)
	72	3-364-439-01	3-364-439-11	KNOB (R)
45	116	*3-350-482-21	*3-350-482-41	PANEL BACK (K970ES)

TC-K333ESL/K970ES


SONY[®] SERVICE MANUAL


AEP Model
TC-K970ES

E Model
TC-K333ESL

CORRECTION-1

Correct your service manual as shown below.

 : indicates corrected portion.

Page	INCORRECT			CORRECT		
58	<u>Ref No.</u> RY503	<u>Part No.</u> 1-515-614-11	<u>Description</u> RELAY	<u>Ref No.</u> RY503	<u>Part No.</u> 1-515-803-11 	<u>Description</u> RELAY